


# User & Installation Manual

## LT-3100 Satellite Communications System



Document Number: 95-100765 Rev 1.08

Release date: May 2023

Copyright © Lars Thrane A/S

Denmark

ALL RIGHTS RESERVED



**This Document is of © copyright to Lars Thrane A/S. It contains proprietary information, which is disclosed for information purposes only. The contents of this document shall not in whole or in part be used for any other purpose without prior permission from Lars Thrane A/S.**

## Disclaimer

Any responsibility or liability for loss or damage in connection with the use of this product and the accompanying documentation is disclaimed by Lars Thrane A/S. The information in this manual is provided for information purposes only, is subject to change without notice, and may contain errors or inaccuracies. Manuals issued by Lars Thrane A/S are periodically revised and updated. Anyone relying on this information should acquire the most current version e.g. from Lars Thrane A/S. Lars Thrane A/S is not responsible for the content or accuracy of any translations or reproductions, in whole or in part, of this manual from any other source.

## Copyright

© 2023 Lars Thrane A/S. All rights reserved.

## Disposal

Old electrical and electronic equipment marked with this symbol can contain substances hazardous to human beings and the environment. Never dispose these items together with unsorted municipal waste (household waste). In order to protect the environment and ensure the correct recycling of old equipment as well as the re-utilization of individual components, use either public collection or private collection by the local distributor of old electrical and electronic equipment marked with this symbol. Contact the local distributor or dealer for information about what type of return system to use.



## IMO and SOLAS

The equipment described in this manual is intended for use on commercial marine and leisure vessels. The equipment is not covered by the International Maritime Organization (IMO) and Safety of Life at Sea (SOLAS) regulations.

## Safety Instructions for Installer & Operator

The following safety instructions must be observed during all phases of operation, installation, service and repair of this equipment. Failure to comply with these precautions or with specific warnings elsewhere in this manual violates safety standards of design, manufacture and intended use of the equipment.

Lars Thrane A/S assumes no liability for the customer's failure to comply with these requirements.

### Instructions for the Installer



#### **WARNING - Product installation**

To ensure correct performance of this equipment, it is strongly recommended that professionals with expertise, properly trained, and likewise authorized within the industry is completing the installation.

#### **WARNING – Turn off power switch**

Turn off the main power switch before installing the equipment described in this manual. Do not connect or disconnect equipment when the main power switch is on.

#### **WARNING – Use only the supplied cable**

Use only the supplied power and communication cable for connecting the equipment.

#### **WARNING – Input Power**

The input voltage range is: 12-24 VDC (2.2-1.7A).

#### **WARNING – Power supply protection**

Make sure that the power supply is adequately protected by a fuse or an automatic circuit breaker when installing the equipment (15 A).

#### **WARNING - Explosive atmosphere**

Do not operate the equipment in the presence of flammable gases or fumes. Operation of any electrical equipment in such an environment constitutes a definite hazard.

#### **WARNING - Compass safe distance**

The compass safe distance for standard and steering compasses is 1.40 m (4.6 ft) and 0.90 m (3.0 ft) respectively. Observe these distances to prevent interference to a magnetic compass.

### Instructions for the Operator

#### **WARNING – Do not disassemble**

Do not disassemble or modify this equipment. Fire, electrical shock, or serious injury can result.

#### **WARNING – Keep away from live circuits**

Operational personnel must not remove product enclosure. Do not service the equipment with the communication cable connected. Always disconnect and discharge unit, cable and circuits before touching them.

#### **WARNING - Permanent watch**

In case of smoke or water leaks into the equipment, immediately turn off the power. Continued use of the equipment can cause fire or electrical shock. Keep access and permanent watch of the equipment in order to prevent any unwanted escalation.



#### **WARNING – DC mains connector**

The DC mains connector is to be used as the disconnection device to isolate the equipment from the mains supply.



#### **IMPORTANT - Safety distance**

The safety distance from the LT-3130 Antenna Unit, when the LT-3130 Antenna Unit is powered and transmitting, is 0.1 m (0.3 ft), to comply with the regional regulations.

Always keep this safety distance to the LT-3130 Antenna Unit to avoid any serious injury.

**If the safety precautions and warnings on this site are not followed, warranty will be void.**

**IMPORTANT – FCC Compliance Note:**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This product does not contain any user-serviceable parts.

Repairs should only be made by an authorized Lars Thrane A/S service center. Unauthorized repairs or modifications could result in permanent damage to the equipment and void your warranty and your authority to operate this device under Part 15 regulations.

**IMPORTANT – Innovation, Science and Economic Development Canada Compliance Note:**

This device complies with Innovation, Science and Economic Development Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

## Required information for the reader

Throughout this document, essential information will be presented to the reader. The following text (emphasized) has the following meaning and/or implication:

**WARNING:** A 'Warning' is an Operation or Service procedure that, if not avoided, may cause a hazard situation, which could result in personnel death or serious injury.

**IMPORTANT:** Text marked 'Important' provides essential information to the reader and is key information to the user for the equipment to work properly. Damage to the equipment can occur if instructions are not followed.

**NOTE:** A 'Note' provides essential information to the reader.

## About this manual

### Intended readers

This is a User & Installation Manual for LT-3100 Satellite Communications System, or LT-3100 system. The manual is primarily intended for installers and service personnel.

Personnel installing or servicing the system should be professionals with technical expertise, properly trained, and likewise authorized.

All safety instructions and guidelines in this manual must be observed. The safety instructions are listed in the beginning of the manual. The guidelines are to be found in the separate chapters, where it is needed.

## Software versions

This manual is applicable to the following software:

| Software Versions |           |         |
|-------------------|-----------|---------|
| Description       | P/N       | Version |
| LT-3100 system    | 71-101301 | 1.15R   |

*Table 1: Software Versions*

**IMPORTANT:** The latest software released by Lars Thrane A/S must always be used for new installations of the LT-3100 System and should be updated to ensure the best possible performance of the system and services.

**NOTE:** The latest LT-3100 Software and Release Notes can always be downloaded from the Lars Thrane A/S website. Please contact Lars Thrane A/S for details about future software releases and features.

## Record of Revisions

| Rev. | Description   | Release Date     | Initials |
|------|---|------------------|----------|
| 1.00 | Original document.  | January 12, 2018 | PT       |
| 1.01 | Editorial corrections.  | January 17, 2018 | PT       |
| 1.02 | As a result of the certification completed, the following sections are updated:<br>Safety Instructions for Installer & Operator<br>App. A - Specifications  | May 29, 2018     | PT       |
| 1.03 | As a result of the certification process, the following sections are updated:<br>Safety Instructions for Installer & Operator   | July 13, 2018    | CT       |
| 1.04 | As a result of the FCC certification process, the following sections are updated:<br>Safety Instructions for Installer & Operator   | November 5, 2018 | CT       |
| 1.05 | As a result of the RED certification process, the following sections are updated:<br>Frequencies band utilized (App. A)<br>Maximum RF output powers for Iridium & BT transmitters (App. A)<br>EU Declaration of Conformity (App. J)   | March 12, 2019   | CT       |
| 1.06 | Updated and added several chapters (incl.):<br>Tracking<br>Bridge Alert Management (BAM)<br>Data (Modem Data, SMS, and SBD)<br>Bluetooth<br>NMEA 0183 GNSS over UDP (broadcast on LAN or Bluetooth)<br>Web Server User login<br>External SIP Phones<br>Web Server Contacts  | January, 2022    | KTL      |
| 1.07 | Updated LT-3110 Control Unit Input Power  | April, 2023      | KTL      |
| 1.08 | Updated and added several chapters (incl.)<br>DNS<br>Outgoing firewall<br>PPPoE<br>Removed Bracket Mount (1.5" to 2.5" pipe), Antenna Unit<br>Updated Galvanic Isolated Power Supply<br>Added Note on Bluetooth module availability for LT-3110 CU<br>Editorial Corrections | May, 2023        | KTL      |



## Table of Contents

|  |    |
|--|----|
| Introduction .....                                 | 1  |
| Application and Limitations.....                   | 2  |
| Unpacking (in-the-box) .....                       | 3  |
| Inspection.....                                    | 3  |
| Accessories.....                                   | 4  |
| Mounts .....                                       | 4  |
| Cable and connectors .....                         | 4  |
| System Overview .....                              | 5  |
| Installation and Mounting.....                     | 6  |
| LT-3110 Control Unit.....                          | 6  |
| LT-3120 Handset .....                              | 9  |
| LT-3121 Cradle.....                                | 10 |
| LT-3130 Antenna Unit.....                          | 11 |
| Pole Mount (1.5" pipe, 38.8 mm), Antenna Unit..... | 19 |
| Pole Mount (2.0" pipe, 53.0 mm), Antenna Unit..... | 21 |
| Interfaces.....                                    | 23 |
| LT-3110 Control Unit.....                          | 23 |
| LT-3130 Antenna Unit.....                          | 32 |
| Power Consumption .....                            | 34 |
| Maximum .....                                      | 34 |
| DC Isolation Resistance and Chassis Ground .....   | 35 |
| Galvanic Isolated Power Supply .....               | 37 |
| AC/DC Galvanic Isolated Power Supply .....         | 37 |
| DC/DC Galvanic Isolated Power Supply .....         | 37 |
| User Interface (UI).....                           | 38 |
| Display.....                                       | 39 |
| Menu System .....                                  | 43 |
| Activating the System .....                        | 45 |
| Acquire a SIM Card.....                            | 46 |
| Who's My Service Provider .....                    | 47 |
| Change of Hardware and Software .....              | 48 |
| Change of Hardware .....                           | 48 |
| Software Update.....                               | 49 |

|   |     |
|---|-----|
| <b>System Services</b> .....                                  | 50  |
| <b>Voice call</b> .....                                       | 50  |
| <b>SMS</b> .....  | 56  |
| <b>External SIP Phones</b> .....                              | 61  |
| <b>Analogue Phone Adapter</b> .....                           | 63  |
| <b>Data (Modem Data, SMS and SBD)</b> .....                   | 64  |
| <b>Tracking</b> .....   | 69  |
| <b>Bluetooth</b> .....  | 72  |
| <b>System Submenus</b> .....                                  | 75  |
| <b>Phone</b> .....  | 75  |
| <b>Settings</b> .....   | 79  |
| <b>System</b> .....   | 86  |
| <b>Bridge Alert Management (BAM)</b> .....                    | 91  |
| <b>Serial Interface (RS-422)</b> .....                        | 95  |
| <b>GNSS sentences</b> .....                                   | 95  |
| <b>BAM sentences</b> .....                                    | 96  |
| <b>NMEA 0183 over UDP</b> .....                               | 97  |
| <b>Web server</b> .....                                       | 98  |
| <b>Accessing the built-in web server</b> .....                | 99  |
| <b>Dashboard</b> .....  | 100 |
| <b>Messages</b> .....   | 101 |
| <b>Configuration</b> .....                                    | 103 |
| <b>Maintenance</b> .....                                      | 133 |
| <b>Legal notice</b> .....                                     | 135 |
| <b>Log out</b> .....  | 135 |
| <b>Disable login timeout</b> .....                            | 135 |
| <b>Service &amp; Repair</b> .....                             | 136 |
| <b>Appendixes</b> .....                                       | 137 |
| <b>App. A - Applicable Standards</b> .....                    | 137 |
| <b>App. B - Bridge Alert Management (BAM)</b> .....           | 138 |
| <b>App. C - Multiple talkers and multiple listeners</b> ..... | 143 |
| <b>App. D - GNSS sentences</b> .....                          | 144 |
| <b>App. E - BAM Sentences</b> .....                           | 145 |
| <b>App. F - GNSS Receiver Integrity States</b> .....          | 146 |

|  |            |
|--|------------|
| <b>App. G - Specifications .....</b>   | <b>151</b> |
| <b>App. H - Outline Drawing: LT-3110 Control Unit.....</b>                           | <b>152</b> |
| <b>App. I - Outline Drawing: Bracket Mount, Control Unit .....</b>                   | <b>153</b> |
| <b>App. J - Outline Drawing: Flush Mount, Control Unit.....</b>                      | <b>154</b> |
| <b>App. K - Outline Drawing: LT-3130 Antenna Unit .....</b>                          | <b>155</b> |
| <b>App. L - Outline Drawing: Pole Mount (1.5" pipe, 38.8mm), Antenna Unit .....</b>  | <b>156</b> |
| <b>App. M - Outline Drawing: Pole Mount (2.0" pipe, 53.0 mm), Antenna Unit .....</b> | <b>157</b> |
| <b>App. N - Outline Drawing: LT-3120 Handset .....</b>                               | <b>158</b> |
| <b>App. O - Outline Drawing: LT-3121 Cradle .....</b>                                | <b>159</b> |
| <b>App. P - EU Declaration of Conformity.....</b>                                    | <b>160</b> |

## Introduction

Congratulations on your purchase of the LT-3100 Satellite Communications system!

The LT-3100 Satellite Communications System is a maritime satellite communication product from Lars Thrane A/S. The LT-3100 system is designed for the professional market (deep sea, fishing, and workboats), but can be used for the leisure market as well. The LT-3100 system meets all standards and certification requirements needed for worldwide maritime satellite communication equipment.

The LT-3100 system has voice and data capabilities with 100% global coverage provided by the Iridium® Communications Network.

The LT-3100 system consists of a control unit, antenna unit, handset and cradle.

A single coaxial cable connects the control unit with the antenna unit. Using a standard coaxial cable, up to 500 meters of separation between the units can be obtained, giving freedom to mount the antenna unit in the best possible location, with free line of sight to the Iridium satellites.

The LT-3100 system can be used as the primary satellite communication product on vessels, covering the basic communication needs in terms of connectivity between the ship and shore and ship to ship.

## Application and Limitations

- The LT-3100 system shall be installed according to manufacturer's User & Installation Manual.
- The LT-3100 system includes an integrated Global Navigation Satellite System (GNSS) receiver for position fixing.
- The LT-3130 Antenna Unit operational low temperature is:
  - -30°C (-22°F) when using 12 VDC input power on the LT-3110 Control Unit
  - -40°C (-40°F) when using 24 VDC input power on the LT-3110 Control Unit

## Unpacking (in-the-box)

Unpack the LT-3100 Satellite Communications System – Basic (P/N: 90-101142) and check that the following items are present in the box:

- 51-100987 LT-3110 Control Unit
- 51-100988 LT-3120 Handset
- 51-101181 LT-3121 Cradle
- 51-100989 LT-3130 Antenna Unit
- 91-100771 Bracket Mount, Control Unit
- 91-102118 Power Cable, 3m
- 4 x Stainless steel A4 screws (for Bracket Mount, Control Unit)
- 2 x Stainless steel A4 screws (for Cradle)
- 4 x Unit Test Sheets
- 95-100765 LT-3100 User & Installation Manual

**NOTE:** Antenna unit mounts (bracket and pole mount) are not included in the LT-3100 Satellite Communications System - Basic (P/N: 90-101142) and must be ordered separately. The antenna unit must only be mounted, using the bracket or pole mount, delivered by Lars Thrane A/S. The antenna unit mounts are listed with part numbers (P/N) in *Accessories* on page 4.

### Inspection

Inspect the shipping cartons and/or wooden box immediately upon receipt for evidence of damage during transport. If the shipping material is severely damaged or water stained, request that the carrier's agent is present when opening the cartons and/or wooden box. Save all box packing material for future use.

After unpacking the system and opening the cartons, inspect it thoroughly for hidden damage and loose components or fittings. If the contents are incomplete, if there is mechanical damage or defect, or if the system does not work properly, notify your distributor.

**WARNING:** To avoid electric shock, do not apply power to the LT-3100 system components if there is any sign of shipping damage to any part of a unit or the outer cover. Read the Safety Instructions at the front of this manual before installing or operating the system.

## Accessories

### Mounts

The following accessory parts are not part of the basic system and must be ordered separately:

- 91-100772 Flush Mount, Control Unit
- 91-100774 Pole Mount (1.5" pipe, 38.8mm), Antenna Unit
- 91-102520 Pole Mount (2.0" pipe, 53.0 mm), Antenna Unit

### Cable and connectors

The following cable and connector parts are not part of the basic system and must be ordered separately:

- 91-100768 Aux Cable, 3m
- 91-101183 Coaxial cable Ø4.9mm, 10m
- 91-101184 Coaxial cable Ø4.9mm, 25m
- 91-101137 Coaxial Cable Ø10.3mm 10m
- 91-101138 Coaxial Cable Ø10.3mm 25m
- 91-101139 Coaxial Cable Ø10.3mm 50m
- 91-101140 N Conn. (male) for Coaxial Cable Ø4.9mm
- 91-101186 N Conn. (male) for Coaxial Cable Ø10.3mm
- 91-101187 Crimping Tool for Coaxial Cable Ø4.9mm
- 91-101188 Crimping Tool for Coaxial Cable Ø10.3mm

Coaxial cables are delivered with one fixed N connector (outdoor mounting), another loose N connector and crimp parts comes with the cable. It is required to use an appropriate crimping tool for attaching the loose N connector.

**NOTE:** For further details on the cable and connectors, please contact Lars Thrane A/S. A coaxial cable up to a length of 500 meters can be used for connecting the LT-3110 Control Unit and the LT-3130 Antenna Unit. Details about the coaxial cable, specification, and cable lengths, are described in *LT-3130 Antenna Unit* on page 11.

## System Overview

The LT-3100 Satellite Communications System is a standalone communication product, which uses the Iridium® satellite constellation. The LT-3100 system is working on the new Iridium® NEXT satellites. An overview of the LT-3100 system is illustrated in Figure 1.




Figure 1: LT-3100 system - basic components and interfaces.

The LT-3100 system consists of the following units, provided by Lars Thrane A/S:

- LT-3110 Control Unit
- LT-3120 Handset
- LT-3121 Cradle
- LT-3130 Antenna Unit

**NOTE:** The built-in Bluetooth module and functionality will not be available in future production of the LT-3110 Control Unit due to manufacturer shortage and component obsolescence. In the display / GUI (MENU -> Settings -> Bluetooth) it can be verified if the Bluetooth module is mounted or not (the Bluetooth submenu will only be shown if the module is mounted).



## Installation and Mounting

### LT-3110 Control Unit

The LT-3110 Control Unit is the master unit in the system, supporting all external interfaces and the operational user interface. The LT-3110 Control Unit is designed for indoor mounting. Check the specifications in *App. G - Specifications* on page 151.




Figure 2: LT-3110 Control Unit (front view)

The LT-3110 Control Unit has the following interfaces:

- 4-pin power connector (male), marked 'PWR'
- Chassis ground connector, marked 'GNDC'
- N connector (female) for coaxial cable to the LT-3130 Antenna Unit, marked 'ANT'
- Ethernet (RJ-45) connector, marked 'LAN'
- 10-pin auxiliary connector (male), marked 'AUX'
- SIM card, marked 'SIM'
- 5-pin connector (female) for LT-3120 Handset (front of the control unit)

The interfaces on the back side of the LT-3110 Control Unit are illustrated in Figure 3 on page 7.

The LT-3110 Control Unit interfaces are described in *Interfaces on page 23*. The LT-3110 Control Unit, front and backside view, are illustrated in Figure 2 and Figure 3.




Figure 3: LT-3110 Control Unit (backside view).

The LT-3110 Control Unit user interface, display and buttons, are described in *User Interface (UI) on page 38*.

**NOTE:** The LT-3110 Control Unit must be mounted with either the Bracket Mount, Control Unit (P/N: 91-100771) or Flush Mount, Control Unit (P/N: 91-100772) - illustrated in Figure 4 and Figure 5. The Flush Mount, Control Unit is not included in the LT-3100 Satellite Communications System – Basic (P/N: 90-101142) and must be ordered separately.

#### Mounting and installation considerations:

For optimum system performance, the following guidelines on where to install and mount the LT-3110 Control Unit must be followed. It is recommended to mount the unit in a location, which fulfills these requirements:

- Mount the unit indoor (not exposed to direct water)
- Mount the unit using either the bracket mount or flush mount
- Mount the unit on a rigid structure with a minimum of exposure to vibration and shock
- Mount the unit in an area with an ambient temperature between -15°C to +55°C (+5°F to +131°F)

The Bracket Mount and Flush Mount for the LT-3110 Control Unit are illustrated in Figure 4 and Figure 5.




Figure 4: Bracket Mount, Control Unit.




Figure 5: Flush Mount, Control Unit.

### LT-3120 Handset

The LT-3120 Handset is the primary voice interface for the LT-3100 system. The LT-3120 Handset must be connected on the front of the LT-3110 Control Unit. The connector is illustrated in Figure 2 on page 6.




Figure 6: LT-3120 Handset (front view).

The LT-3120 Handset is connected to the LT-3110 Control Unit via a 5-pin proprietary angle connector. The spiral cord, fixed to the LT-3120 Handset is ~ 0.4 m from handset to connector, when coiled. The spiral cord can be stretched to a maximum of 2 m. The LT-3120 Handset is designed for indoor mounting. Check the specifications in *App. G - Specifications* on page 151.

The LT-3120 Handset has the following characteristics:

- High-performance audio speaker and microphone
- Separate ringer (buzzer)
- Speaker volume control (double-button, marked with '+' and '-', for volume up and down)
- Built-in off-hook detection circuit




Figure 7: LT-3121 Handset (back view)

**NOTE:** The LT-3110 Control Unit will inform the user if the LT-3120 handset is not properly connected to the LT-3110 Control Unit. A BAM alert will be activated (Lost handset).

**NOTE:** The LT-3120 Handset must be operated together with the LT-3121 Cradle, for the off-hook detection circuit to work. The LT-3121 Cradle is described in *LT-3121 Cradle* on page 10.

### LT-3121 Cradle

The LT-3121 Cradle is used together with the LT-3120 Handset. The LT-3121 Cradle should be mounted next to the LT-3110 Control Unit, supporting the LT-3120 Handset. The LT-3121 Cradle specifications are available in *App. G - Specifications* on page 151.




Figure 9: LT-3121 Cradle (front view).




Figure 8: LT-3121 Cradle (backside view)

**IMPORTANT:** The LT-3121 Cradle contains a magnet, to hold on to the LT-3120 Handset. Make sure that other electronic equipment is installed in a distance respecting the compass safe distance of 0.4 m (1.3 ft).

An outline drawing for the LT-3121 Cradle is available in *App. O - Outline Drawing: LT-3121 Cradle* on page 159.

### LT-3130 Antenna Unit

The LT-3130 Antenna Unit is designed for outdoor mounting and connected to the LT-3110 Control Unit via a coaxial cable. The LT-3130 Antenna Unit specifications are available in *App. G - Specifications* on page 151. The LT-3130 Antenna Unit has an N connector (female) mounted, centered at the bottom of the antenna.




Figure 10: LT-3130 Antenna Unit.

The LT-3130 Antenna Unit has an N connector (female) at the bottom side of the unit.

#### Mounting and installation considerations:

- Mount the unit vertically (with the N connector pointing down)
- Mount the unit with free line of sight to the Iridium® and GNSS satellites. Make sure that the unit can receive signals from the Iridium® and GNSS satellites (satellite reception information is available in the LT-3110 Control Unit user interface display, see Figure 36 on page 39)
- Mount the unit on a rigid structure with a minimum of exposure to vibration and shock
- Mount the unit using the Pole Mount provided by Lars Thrane A/S
- Mount the unit outdoor with an ambient temperature between -40°C to +55°C (-40°F to +131°F)
- Mount the unit with a minimum angle of 20 degrees towards a radar antenna (above or below) and keep a minimum distance of 2.5 m (8 ft)
- Mount the unit at least 1 m. (3 ft.) away from radio transmitting antennas (VHF, UHF, MF-HF)
- Mount the unit away from Inmarsat and transmitting VSAT antennas

**NOTE:** It is only the LT-3130 Antenna Unit marked with HVIN 2.00 (Unit Label) or newer that can be used for the LT-3100 Satellite Communications System. The LT-3100 software will check the antenna unit during power up and the system will not be operational, if connecting a legacy LT-3130 Antenna Unit.

To avoid breaking the LT-3130 Antenna Unit N-connector (female), it is important not to use tooling when connecting and fastening the coaxial cable N-connector (male) to the antenna unit. The coaxial cable N-connector thread nut must be fastened by hand only.



Figure 11: Connecting coaxial cable N-connector to the LT-3130 Antenna Unit

**IMPORTANT:** Maximum allowed torque is 2 Nm when connecting the coaxial cable N-connector (male) to the N-connector (female) of the LT-3130 Antenna Unit. No tooling must be used for fastening the coaxial cable thread nut as illustrated in Figure 11 above.

The LT-3130 Antenna Unit has a hazard warning label attached to the radome as illustrated in Figure 12.




Figure 12: LT-3130 Antenna Unit (incl. warning label)

**WARNING:** The safety distance from the LT-3130 Antenna Unit, is 0.1 m (0.3 ft), in order to comply with the regional regulations.

**IMPORTANT:** Due to the adjacency of the Iridium and Inmarsat frequency bands, the LT-3130 Antenna Unit may not co-operate in the proximity of an active Inmarsat antenna unit, see *Coexisting with Inmarsat L-band* on page 18



The LT-3130 Antenna Unit must be installed outside the main beam of the radar. Typically, this is in the order of 10 degrees. To avoid near field antenna coupling, a minimum distance of 2.5 m (6 ft) between the radar antenna and the LT-3130 Antenna Unit must be obeyed. Figure 13 is illustrating how the LT-3130 Antenna Unit should be mounted to avoid interference from radars.




Figure 13: LT-3130 Antenna Unit – Avoid Radar Beam.

**IMPORTANT:** Failing to obey the specified installation conditions will void the warranty. However, depending on the specific radar frequency and power level, the separation distance between the radar and the LT-3130 Antenna Unit may be reduced, with no impact on the antenna performance. The performance of the LT-3130 Antenna Unit should be validated when the LT-3100 system is installed.

The LT-3130 Antenna Unit must be mounted minimum 1 m from MF-HF, VHF, and UHF antennas.




Figure 14: LT-3130 Antenna Unit – Separation to MF-HF, VHF, and UHF antennas.

**NOTE:** The LT-3130 Antenna Unit must be installed with a 360° clear view of the sky. However, minor obstructions such as a mast will not degrade the antenna performance severely, if a separation distance larger than 15 times the diameter of the obstruction is kept.




Figure 15: LT-3130 Antenna Unit – (separation distance to minor obstructions)

The LT-3130 Antenna Unit must be mounted using one of the mounts listed in Mounts on page 4

The LT-3130 Antenna Unit must be mounted with free line of sight to the Iridium satellites for best possible performance. The best location will typically be at the top of the lantern mast, where there are no obstructions blocking the Iridium satellite link. The LT-3130 Antenna Unit is designed to maintain a communication link to the Iridium satellites in all weather conditions, see Table 2.

| Extreme Ship Motion Values & Clear View Angles Below the Horizontal Plan |                   |                        |  |
|--|-------------------|------------------------|--|
| Motion Direction   | Maximum Amplitude | Iridium Satellite Acq. | Clear View Angle Below the Horizontal Plan |
| Roll   | ±30°              | +8°                    | -22°                                       |
| Pitch  | ±10°              | +8°                    | -2°  |

Table 2: LT-3130 AU Roll and Pitch Clear View Angles (below the horizontal plan)




Figure 16: LT-3130 AU Installation (roll: clear view angle below the horizontal plan)

**NOTE:** The LT-3130 Antenna Unit must be mounted with a -22° clear view angle below the horizontal plan (port and starboard directions), where no obstructions must block the Iridium satellite signal, to maintain full functionality under extreme roll conditions. Also, the upper hemisphere must also be without any blockages to the Iridium satellites.




Figure 17: LT-3130 AU Installation (pitch: clear view angle below the horizontal plan)

**NOTE:** The LT-3130 Antenna Unit must be mounted with a  $-2^\circ$  clear view angle below the horizontal plan (fore and after directions), where no obstructions must block the Iridium satellite signal, to maintain full functionality under extreme pitch conditions. Also, the upper hemisphere must be without any blockages to the Iridium satellites.

**IMPORTANT:** For best possible performance of the LT-3100 system, the LT-3130 Antenna Unit must have free line of sight to the Iridium satellites as illustrated in Figure 16 and in Figure 17 (clear view angle below the horizontal plan). To have the best possible obstructions should be below the marked lines of these two illustrative figures.

**Coexisting with Inmarsat L-band**

It is possible to install the LT-3100 system onboard a vessel that already has Inmarsat C equipment installed.

It is important to note that the LT-3130 Antenna Unit must be mounted below the Inmarsat C antenna with a minimum distance of 1 m and below an angle of minimum 15° when coexistence is required.

Practical use of the LT-3100 system during Alpha and Beta Sea trials, installed onboard vessels with Inmarsat equipment, has not revealed any degradation in system performance.


Survival distances:

Mount the LT-3130 Antenna Unit at a minimum distance of 1 m from an Inmarsat C antenna.

Mount the LT-3130 Antenna Unit at a minimum distance of 3 m from an Inmarsat Fleet Broadband antenna.

**Pole Mount (1.5" pipe, 38.8 mm), Antenna Unit**

The Pole Mount (1.5" pipe), Antenna Unit is illustrated in Figure 18 to Figure 20.



*Figure 18: Pole Mount (1.5" pipe), Antenna Unit.*

**Pole mount installation procedure:**

1. Feed the coaxial cable through the pole mount
2. Fasten the coaxial cable to the LT-3130 Antenna Unit (N connector)
3. Apply self-vulcanic tape on the N connector and cable to protect against saltwater and corrosion
4. Screw the pole mount (clockwise) on the LT-3130 Antenna Unit, and fasten the antenna lock pinot screw, as illustrated in Figure 20 (max torque = 1.2 Nm)
5. The LT-3130 Antenna Unit and pole mount can now be mounted on the 1.5" pipe. Fasten the three pole lock pinot screws, as illustrated in Figure 19 (max torque = 4.5 Nm)

**NOTE:** Remember to fasten the antenna lock pinot screw (1.2 Nm) after the pole mount and antenna unit have been screwed together.

**NOTE:** The Pole Mount (1.5" pipe), Antenna Unit interfaces to a pipe of maximum 1.5" (38.1 mm), measured outer diameter.




Figure 19: Pole Mount (1.5" pipe), Antenna Unit.




Figure 20: Pole Mount (1.5" pipe), Antenna Unit.

**NOTE:**

The Pole Mount (1.5" pipe), Antenna Unit only supports a 1.5" pipe. The pinot screws (antenna and pole lock) torques are specified in Figure 19 and Figure 20. The pole mount is made of milled aluminum (anodized). The pinot screws are made of A4 stainless steel.

**Pole Mount (2.0" pipe, 53.0 mm), Antenna Unit**

The Pole Mount (2.0" pipe, Ø53.0 mm), Antenna Unit is illustrated in Figure 21 to Figure 23.




Figure 21: Pole Mount (2.0" pipe, Ø53.0 mm), Antenna Unit.

**Pole mount installation procedure:**

1. Feed the coaxial cable through the pole mount
2. Fasten the coaxial cable to the LT-3130 Antenna Unit (N connector)
3. Apply self-vulcanic tape on the N connector and cable to protect against saltwater and corrosion
4. Screw the pole mount (clockwise) on the LT-3130 Antenna Unit, and fasten the antenna lock pinot screw, as illustrated in Figure 23 (max torque = 1.2 Nm)
5. The LT-3130 Antenna Unit and pole mount can now be mounted on the 2.0" pipe. Fasten the three pole lock pinot screws, as illustrated in Figure 22 (max torque = 4.5 Nm)

**NOTE:** Remember to fasten the antenna lock pinot screw (1.2 Nm) after the pole mount and antenna unit have been screwed together.

**NOTE:** The Pole Mount (2.0" pipe, Ø53.0 mm), Antenna Unit interfaces to a pipe of maximum 2.0" (53.0 mm), measured outer diameter.






Figure 22: Pole Mount (2.0" pipe, Ø53.0 mm), Antenna Unit.




Figure 23: Pole Mount (2.0" pipe, Ø53.0 mm), Antenna Unit.

**NOTE:** The Pole Mount (2.0" pipe, Ø53.0mm), Antenna Unit only supports a 2.0" pipe. The pinot screws (antenna and pole lock) torques are specified in Figure 22 and Figure 23. The pole mount is made of milled aluminum (anodized). The pinot screws are made of A4 stainless steel.

## Interfaces

### LT-3110 Control Unit

This section will describe all the external interfaces from the LT-3110 Control Unit.




Figure 24: LT-3110 Control Unit (back view)

#### DC input (PWR)

The LT-3100 system is designed to be used on 12 VDC and 24 VDC power buses (nominal). External DC power to the LT-3100 system is provided by connecting the proprietary 91-102118 Power Cable, 3m - delivered by Lars Thrane A/S. The power connector is mounted on the back side of the LT-3110 Control Unit and marked 'PWR', see Figure 24.

The power source for the LT-3100 system must comply with the regulations and the associated standards, minimum is compliance to IEC 60945 (2002). When extending the power supply cables the positive (+) and the negative (-) must be installed closely together in order to keep the cable inductance low.

**NOTE:** Make sure to use a galvanic isolated power supply, see *Galvanic Isolated Power Supply* on page 37.

**NOTE:** The input voltage range is: 12-24 VDC (2.2-1.7A). The LT-3110 Control Unit DC input connector and circuit is protected and certified for *Reverse Polarity Protection*.

**NOTE:** A power connector (4-pole) is used for the LT-3110 Control Unit. This power connector requires the new 91-102118 power cable, 3m from Lars Thrane A/S. Use only the 91-102118 power cable, 3m delivered by Lars Thrane A/S. If power connector (2-pole) is used for the LT-3110 Control Unit, then use the 91-100767 power cable, 3m delivered by Lars Thrane A/S.

**NOTE:** The LT-3110S Control Unit must be connected to the power supply using a 15 A circuit breaker. See *Galvanic Isolated Power Supply* on page 37.

**Chassis ground**

The chassis ground connector is placed on the back side of the LT-3110 Control Unit and marked with 'GNDC', see Figure 24 on page 23.

### SIM card (SIM)

The LT-3100 system requires a SIM card to be operated with the Iridium® satellite services. The Iridium® SIM card must be bought from one of the official Iridium® Service Providers. A list of Iridium® Service Providers can be found at the Iridium® website: <https://www.iridium.com> (select 'Services', and hereafter 'Voice').

The SIM card must be inserted in the LT-3110 Control Unit behind the rubber dust cover. Make sure that the LT-3110 Control Unit is powered off before opening the rubber dust cover. When the SIM card is properly inserted in the slot, and the rubber dust cover is secured, the LT-3110 Control Unit can be powered up. The rubber dust cover is illustrated in Figure 24 on page 23 and marked with 'SIM'.

The following procedure must be followed when inserting, replacing, or removing the SIM card:

1. Turn off the power to the LT-3110 Control Unit
2. Remove the rubber dust cover on the back side of the LT-3110 Control Unit
3. Slide the SIM card holder as illustrated with the arrows on the PCB print, to unlock
4. Open the SIM card holder and insert or remove the SIM card
5. Close the SIM card holder
6. Slide the SIM card holder as illustrated with the arrows on the PCB (opposite direction), to lock
7. Re-insert the rubber dust cover
8. Turn on power to the LT-3110 Control Unit

**NOTE:** The LT-3110 Control Unit must be powered off when inserting, changing, or removing the SIM card. The SIM card is hidden behind the rubber dust cover on the back side of the LT-3110 Control Unit.

Figure 25 is showing an Iridium SIM card. The format is Mini-SIM (2FF) 25 x 15 mm. The SIM card must be removed from the full-sized card carrier by breaking the Mini-SIM out. The full-sized card carrier contains the MSISDN number, while the SIM card itself contains the ICCID.



Figure 25: Iridium SIM card

The SIM card will be delivered from the Iridium Service Provider (ISP) together with the essential information:

- MSISDN number (the Iridium voice number)
- ICC-ID
- PIN codes
- PUK codes

The SIM card will be delivered with the SIM lock feature disabled. Thus, the LT-3100 system will be operational as soon as the SIM card is inserted.

If the user decides to activate the SIM lock function from the UI display, then the PIN code is required next time the LT-3100 system is powered up. Change of the SIM card PIN code can only be performed, if the PIN lock is enabled. If changing the SIM card PIN code, then the SIM card default PIN code cannot be restored, and the new PIN code must be used to unlock the SIM card and the Iridium services.

### **Ethernet RJ45 (LAN)**

The LT-3110 Control Unit has an Ethernet LAN (RJ-45) interface, currently supporting service & maintenance. The Ethernet interface must be used to access the built-in web server, which is further described in *Web server* on page 98.

The LT-3110 Control Unit will automatically request and obtain an IP address when connected to a Local Area Network (LAN) with a DHCP server (e.g. a router). If connecting the LT-3110 Control Unit directly to a PC, the two will automatically negotiate an IPv4 Link-Local address. The current IP address can be found in the user interface display (Menu -> System -> Network: IP Address).

**Auxiliary (AUX)**

The auxiliary connector is a 10-pin connector (male) mounted on the backside of the LT-3110 Control Unit as illustrated in Figure 24 on page 23 and marked with ‘AUX’. The auxiliary connector supports the following interfaces.

- RS-422 serial interface
- 2 x Input/output (I/O)

The Auxiliary connector / cable pin out and wire designation are illustrated in Figure 26, Figure 27, and in Table 3.



Figure 26: AUX connector pin out



Figure 27: AUX cable pin out

| Auxiliary (AUX) Cable |            |                          |
|-----------------------|------------|--------------------------|
| Pin No.               | Wire Color | Wire Designation         |
| 1                     | Black      | External Ringer (ground) |
| 2                     | Brown      | External Ringer (output) |
| 3                     | Red        | RS422 Z (output) TxD-    |
| 4                     | Orange     | RS422 Y (output) TxD+    |
| 5                     | Yellow     | RS422 A (input) RxD+     |
| 6                     | Green      | RS422 B (input) RxD-     |
| 7                     | Blue       | Radio Silence (input)    |
| 8                     | Violet     | Radio Silence (ground)   |
| 9                     | Gray       | Not Used                 |
| 10                    | White      | RS422 C (ground)         |

Table 3: AUX Cable

**NOTE:** Use only the 91-100768 Auxiliary Cable, 3m delivered by Lars Thrane A/S for connecting to the AUX connector on the backside of the LT-3110 Control Unit. The Auxiliary Cable, 3m is an accessory part and must be acquired separately.

The LT-3110 Control Unit is supporting external ringer functionality on the Auxiliary (External I/O) interface, which can be configured from the web server, see *External – I/O* on page 127.

The LT-3110 Control Unit is supporting GNSS and BAM on the Auxiliary (RS-422) interface, which can be configured from the web server, see *GNSS and BAM* on page 128.

External Output and Input are further described on the next pages.

RS-422 Circuit Diagram (LT-3110 CU – Aux Connector)

Figure 28 shows the RS-422 circuit diagram used for the LT-3110 Control Unit (Aux connector).




Figure 28: RS-422 Circuit Diagram for the LT-3110 CU

Interface Drive Capability as a Talker and Listener

- A(Rx+), B(Rx-), Y(Tx-): -60V to +60V
- Short circuit protected
- Galvanic isolated up to 1500V

External Output (External Ringer)

The LT-3100 system supports connection of an external speaker for incoming call notifications. Connection of the external speaker must be completed as illustrated in Figure 29, incl. a relay. The maximum voltage and current for the relay are illustrated in the figure. Aux Cable Pin 2 External Output (Pin2) and External Output (Pin1) designation and wire colors are listed in Table 3 on page 27.




Figure 29: External Ringer diagram

**NOTE:** The External Ringer functionality must be configured in the web server, Configuration – External I/O, described in *External – I/O* on page 127.

External Input

The LT-3100 system does not support any functionality for the External I/O Input.

RS-422 (GNSS, BAM, and MSI)

The LT-3100 system Auxiliary RS-422 (bi-directional) interface can be configured to support different functions. The following functions are supported:

- GNSS (see *GNSS sentences* on page 95)
- BAM (see *BAM sentences* page 96)

The RS-422 interface can be configured using the web server, see *GNSS and BAM* on page 128.



**N Connector (ANT)**

The LT-3110 Control Unit has a N Connector (male) for the interface to the LT-3130 Antenna Unit. The N Connector interface is providing data communication and power to the antenna unit over a coaxial cable. The N connector marked with 'ANT' is illustrated on Figure 3 on page 7.

**NOTE:** Do not connect or disconnect the antenna cable when the LT-3110 Control Unit is powered.

**Bluetooth**

The LT-3110 Control Unit has built in Bluetooth 4.0 with integrated antenna providing wireless communication between Bluetooth capable devices and the LT-3100 system.

Max Power: RF Tx Power 10 dBm

**NOTE:** The Bluetooth interface and pairing is described in *Bluetooth* on page 72.

**NOTE:** The built-in Bluetooth module and functionality will not be available in future production of the LT-3110 Control Unit due to manufacturer shortage and component obsolescence. In the display / GUI (MENU -> Settings -> Bluetooth) it can be verified if the Bluetooth module is mounted or not (the Bluetooth submenu will only be shown if the module is mounted).

**LT-3130 Antenna Unit**

The LT-3110 Control Unit and the LT-3130 Antenna Unit must be connected using a coaxial cable. Both the control unit and the antenna unit have a N connector (female) mounted. This section will specify the

| RF Coaxial Cable Requirements |                       |
|-------------------------------|-----------------------|
| Requirement                   | Specification         |
| Cable impedance               | 50 Ω                  |
| Maximum signal loss           | 45 dB/100 m @ 1.5 GHz |

Table 4: RF Coaxial Cable Requirements

requirements to the coaxial cable. The RF and DC requirements are specified in Table 4 and Table 5.

In most cases it will be the DC resistance that will determine the maximum length of the coaxial cable. It is important to note that the input voltage of the control unit is important for the length of the coaxial cable that can be used.

| DC Coaxial Cable Requirements |                       |
|-------------------------------|-----------------------|
| Power Source                  | Maximum DC Resistance |
| 12 VDC                        | 1.7 Ω                 |
| 24 VDC                        | 5.5 Ω                 |

Table 5: DC Coaxial Cable Requirements

**NOTE:** The DC coaxial cable resistance that is listed in Table 5 and used to calculate the maximum cable length is the sum of the DC inner conductor resistance and the DC outer conductor resistance. Some data sheets are not providing enough information about the DC resistance, in which cases, the cable manufacture must be approached to obtain this information.

Lars Thrane A/S has calculated the maximum allowed cable lengths with two coaxial cables as illustrated in Table 6. The two coaxial cables are FF195LSFROH (~RG-58) and FF400LSFROH (~RG-214/LMR400).

| Maximum Coaxial Cable Length |               |               |
|------------------------------|---------------|---------------|
| Cable Type                   | 12 VDC Supply | 24 VDC Supply |
| FF195LSFROH (4.9mm)          | 41 m          | 135 m         |
| FF400LSFROH (10.3mm)         | 154 m         | 500 m         |

Table 6: Maximum coaxial cable length (cable examples)

The cable lengths calculated in Table 6 are obtained by using the maximum DC resistance [Ω] from Table 5 and compare these maximum DC requirements with the actual DC resistance [Ω/km] of the specific coaxial cables. The FF400LSFROH and FF195LSFROX total DC resistance numbers are listed in Table 7 on page 33.

The total DC resistance for the two cables (FF195LSFROH and FF400LSFROH) are:

| Total DC Resistance (Inner and Outer Conductor) |   |   |                                     |
|---|---|---|-------------------------------------|
| Cable Type                                      | Inner Conductor DC Resistance [ $\Omega$ /km] | Outer Conductor DC Resistance [ $\Omega$ /km] | Total DC Resistance [ $\Omega$ /km] |
| FF195LSFROH (4.9 mm)                            | 24.9  | 15.8  | 40.7                                |
| FF400LSFROH (10.3 mm)                           | 4.5   | 6.5   | 11                                  |

*Table 7: Total DC resistance (cable examples)*

**IMPORTANT:** If using a coaxial cable that is different to what is specified in this section (FF195LSFROH and FF400LSFROH), then verify that the RF and DC coaxial cable requirements (Table 4 and Table 5) are respected and calculate the maximum cable length as a function of the input voltage and the total DC resistance. Contact Lars Thrane A/S to get assistance on selection and acceptance of a specific coaxial cable.

**NOTE:** The LT-3110 Control Unit must be powered off when connecting or disconnecting the LT-3130 Antenna Unit.

## Power Consumption

The LT-3100 system is powered from 12 VDC or 24 VDC power source. This section will provide power consumption details for maximum power consumption and typical average power consumption.

### Maximum

The LT-3100 system maximum power consumption is listed in Table 8 and in Table 9. The maximum power consumption is calculated with activity on all interfaces. The LT-3130 Antenna Unit has a built-in heater, which is activated only when the 24 VDC input power source is available.

| 24 VDC Maximum Power Consumption (Watt) |           |
|---|-----------|
| System Unit                             | Power [W] |
| Total Power (maximum)                   | 40.8      |

Table 8: Maximum Power Consumption (24 VDC input)

| 12 VDC Maximum Power Consumption (Watt) |           |
|---|-----------|
| System Units                            | Power [W] |
| Total Power (maximum)                   | 26.4      |

Table 9: Maximum Power Consumption (12 VDC input)

The coaxial cable length is an adding factor to the total power consumption of the system. A short coaxial cable will add approximately ~0 W to the total power consumption. Whereas a coaxial cable with a maximum length will add ~16 W (24 VDC input) and ~10 W (12 VDC input) to the total power consumption. The supported coaxial cable lengths for the LT-3100 system are described in *LT-3130 Antenna Unit* on page 32.

## DC Isolation Resistance and Chassis Ground

The LT-3100 system must be installed properly with respect to DC isolation resistance and chassis ground. Wrong installations can lead to DC isolation issues (low Ohm meter measuring) on board the vessel and equipment damages. This section will provide details about installation precautions, which must be followed.

LT-3110 Control Unit (back view) with an upscaled power connector are illustrated in Figure 30. The Chassis ground (GNDC) must be connected sufficiently to the vessel ground. 91-102218 Power Cable, 3m must be used to connect the LT-3110 Control Unit to the vessel 12 or 24 VDC power source. DC isolation resistance measured on a disconnected LT-3110 Control Unit between GNDC and VDC (-) > 50 MΩ.




Figure 30: LT-3110 Control Unit (VDC(+), VDC(-), and GNDC)

The LT-3130 Antenna Unit (bottom view) is illustrated in Figure 31. Chassis ground (GNDC) on the LT-3130 Antenna Unit is defined as the mechanics (connected to the mounts).




Figure 31: LT-3130 Antenna Unit (VDC(+), VDC(-), and GNDC)

DC isolation resistance measured on a disconnected LT-3130 Antenna Unit between GNDC and VDC (-) > 50 MΩ. VDC (-) and VDC (+) is respectfully the N connector thread and the N connector center conductor. Figure 32 is illustrating the LT-3100 system consisting of LT-3110 Control Unit, LT-3130 Antenna Unit, and the coaxial cable connecting these two units.




Figure 32: Definitions of VDC (+), VDC (-), and GNDC

It is important that the coaxial cable, connected to both the LT-3110 Control Unit and LT-3130 Antenna Unit, is not grounded in any of the ends. Do not connect the coaxial cable shield to vessel ground. The coaxial cable N connector must only be connected directly to the N connector of the two units.

**NOTE:** Make sure that the LT-3130 Antenna Unit is connected sufficiently to vessel ground. Also, make sure that the N connector on the LT-3130 Antenna Unit, VDC (-) is not connected to the LT-3130 Antenna Unit mechanics, GNDC. It is important to adhere to this requirement so as not to get a bad DC isolation resistance.

## Galvanic Isolated Power Supply

Use an IEC 60945 approved AC/DC or DC/DC galvanic isolated power supply for the LT-3100 system. The galvanic isolated power supply must be used to protect the LT-3100.

### AC/DC Galvanic Isolated Power Supply

Connection of an AC/DC galvanic isolated power supply is illustrated in Figure 33.




Figure 33: AC/DC Galvanic Isolated Power Supply

### DC/DC Galvanic Isolated Power Supply

Connection of a DC/DC galvanic isolated power supply is illustrated in Figure 34.




Figure 34: DC/DC Galvanic Isolated Power Supply



## User Interface (UI)

The LT-3100 system is controlled from the LT-3110 Control Unit, which is the interface for operating and configuring the system. The control unit has a 4.3" TFT-LCD display, supporting day and night modes. The




Figure 35: Control Unit (front view) – user interface display and buttons.

layout of the display and buttons is illustrated in Figure 35.

The control unit buttons, function and features, are described in the following groups:

- **Power button:** The power button can power off the system by pressing the button for 5 seconds. A pop-up box will show the action, and a counter will count down until the system is powered off. To Turn the system back on press and hold the power button.
- **Brightness button:** The brightness button has two functions – change of brightness level and change of display mode (day and night). When changing the brightness level, the keypad backlight will be changed as well. Short press (< 1 s); brightness level will change between 7 levels. Long press ( $\geq 1$  s); will change display mode. The display brightness level and display mode can be changed from the UI menu as well (Menu -> Settings -> Display).
- **Off-hook button:** The button is illustrated with a green colored handset. The function of the off-hook button is to activate a call, if the dialled number is available in the display or a contact is selected in the Contacts or Call History. The off-hook button can also be used to accept an incoming call. The alternative to use the off-hook button is to lift the handset out of the cradle. If the off-hook button is used and the handset remain in the cradle, the phone audio will be available in the control unit speaker. The microphone is muted, if the handset remains in the cradle - indicated with an icon in the status bar.
- **On-hook button:** The button is illustrated with a red colored handset. Pressing the on-hook button will terminate an active call.
- **MENU / BAM button:** The MENU button is used to open the main menu. The BACK, Navigation (arrows), and ENTER buttons are used to navigate in the menu. Press the MENU button to exit the menu from anywhere in the menu tree (instead of multiple BACK button presses). Long press (> 1 s) the MENU / BAM button and the BAM Alert List will be shown.
- **Soft keys buttons:** Three soft keys are available in the bottom of the display. The soft keys are used for different purposes and their functions will change in the operation modes of the system.

- Navigation buttons:** The navigation buttons (BACK, arrows, and ENTER) are used for navigation purposes in the menu layout. In context of user input or when making selections, the BACK button will erase input or cancel editing respectfully, the ENTER button will end input or apply selection respectfully. The arrow buttons can be used to change brightness level if the brightness button has activated the brightness bar.
- Numeric Keypad buttons:** The numeric keypad buttons, the '\*' button, and the '+' button can be used for entering digits, letters and special characters. Depending on context, pressing one button in rapid succession (< 1s) will cycle through a selection of letters, digits and/or special characters (e.g. when entering a phone number, pressing the '\*' character twice in succession will result in one '+' character and not two '\*' characters). An icon in the status bar will show the current input mode, indicating which characters can be cycled - if any. In text mode, the '#' key is used to change between capital and lowercase letters.

**Display**

The display contains three sections as illustrated in Figure 36: Status bar, view area and soft keys.




Figure 36: LT-3110 Control Unit - UI display sections

The essential system status and system notifications are shown in the status bar, which is always present.

The view area contains the active view. The active view is changed by navigating the UI using the MENU and navigation buttons. The text and function of the soft keys changes dynamically with the active view. The soft keys can also change without changing view depending on the activity in the active view.

The Recommended viewing distance is 68 cm, at which all data is readable under all light conditions.

The general level of the brightness can be varied through 7 steps from 5 cd/m<sup>2</sup> up to 560 cd/m<sup>2</sup> on white background in “Day mode”. The display also has a “Night mode” (inverted graphics) with additional 7 steps.

It has been verified through measurements that dense text information areas on black background emits light equivalent to 1 cd/m<sup>2</sup>. All measurements through all light levels in the two modes demonstrates a minimum contrast level of 350:1.

The status bar has a dedicated section for presenting time and position and 7 slots for system status icons.




Figure 37: LT-3110 Control Unit - UI (status bar)

**NOTE:** The status bar contains a flashing square in the upper left corner to verify that the display never freezes, see Figure 37 on page 40. The flashing square is always visible on the display.

Each slot shows the status of one function or group of functions. If a group of functions in a slot has more than one active icon, the slot will continuously take turn showing one icon at a time for a few seconds before cycling to the icon of the next function.

| Network Status – Slot 1 |   |
|-------------------------|---|
|                         | The LT-3100 system has no satellite signal and is not registered on the Iridium® Network. |
|                         | The LT-3100 system has satellite signal = 0 and is registered on the Iridium® Network.    |
|                         | The LT-3100 system has satellite signal = 1 and registered on the Iridium® Network.       |
|                         | The LT-3100 system has satellite signal = 5 and registered on the Iridium® Network.       |
|                         | The LT-3100 system has satellite signal = 5 and unregistered on the Iridium® Network.     |

Table 10: LT-3110 Control Unit - UI network status






| <b>Iridium Service – Slot 2</b>   |   |
|---|---|
|  | Active voice call or off-hook mode.                   |
|  | An external (SIP) phone is in an active voice call.   |
|  | Voice service unavailable due to an unspecified error |
|  | There is an active data connection.                   |
|  | Data service unavailable due to an unspecified error  |

Table 11: LT-3110 Control Unit - UI Iridium service




| <b>Notifications – Slot 3</b>   |   |
|---|---|
|  | There are one or more missed calls.                 |
|  | There are one or more voicemail messages.           |
|  | There are one or more unread SMS or Email messages. |

Table 13: LT-3110 Control Unit - UI notifications


| <b>Audio – Slot 4</b>   |   |
|---|---|
|  | The microphone on the handset is muted. |

Table 12: LT-3110 Control Unit - UI audio





| Input Mode – Slot 5   |   |
|---|---|
|  | The numeric keypad can be used to enter a phone number or numeric number.                           |
|  | The numeric keypad can be used to enter text. The first letter of a sentence will be in upper case. |
|  | The numeric keypad can be used to enter text. All letters will be in lower case.                    |
|  | The numeric keypad can be used to enter text. All letters will be in upper case.                    |

Table 14: LT-3110 Control Unit - UI input mode



| Miscellaneous Functions – Slot 6  |                                  |
|---|----------------------------------|
|    | A Bluetooth device is connected. |
|  | The Tracking service is active.  |

Table 15: LT-3110 Control Unit - UI miscellaneous functions







| BAM Status - Slot 7   |   |
|---|---|
|  | Active - unacknowledged warning             |
|  | Active - silenced warning                   |
|  | Active - acknowledged warning               |
|  | Active - responsibility transferred warning |
|  | Rectified - unacknowledged warning          |
|  | Active caution                              |

Table 16: LT-3110 Control Unit - status bar (BAM status)

### Menu System

The LT-3100 system’s main menu is accessed by pressing the MENU button on the keypad. The user will be presented with a layout as illustrated in Figure 38.





Figure 38: LT-3110 Control Unit - UI display (main menu).

The main menu is represented by three sub-menus: Phone, Settings, and System. The three sub-menus are listed in Table 17.

| Sub-menus | Entries   |
|-----------|---|
| Phone     | Contacts<br>SMS<br>Call History<br>Data History<br>Phone Usage                                |
| Settings  | Audio<br>Display<br>Date & Time<br>Phone Setup<br>Bluetooth<br>Security<br>Reset Options      |
| System    | BAM Alerts<br>Network<br>Tracking<br>SIP Phones<br>GNSS Status<br>System Info<br>Power Supply |


Table 17: LT-3110 Control Unit, sub-menu layout.

The three sub-menus are seen on Figure 39 and Figure 40 and Figure 41




Phone submenu:  
MENU -> Phone

Figure 39: Phone submenu



Settings submenu:  
MENU -> Settings

Figure 40: Settings submenu



System submenu:  
MENU -> System

Figure 41: System submenu

## Activating the System

A few things must be completed before you can have an operational LT-3100 system on board your vessel. It is assumed that you have received the LT-3100 system from the Lars Thrane A/S certified partner - this could be directly or indirectly. The Lars Thrane A/S certified partners have completed technical training and will be able to assist you with all the questions you might have to the product or service. The Lars Thrane A/S certified partners are listed on the company's website: <https://www.thrane.eu>

The following is required for activating the LT-3100 system:

- SIM card

The LT-3100 system installation and mounting is described in the previous sections.

**IMPORTANT:** In order for the LT-3100 system to be deemed operational and ready for continuous service: i) it must be correctly installed per the specifications in the User & Installation Manual of the LT-3100 Satellite Communications System ("LT-3100 User & Installation Manual"), ii) the Iridium SIM card, which serves to evidence that a terminal has been subscribed to Iridium's Network, has been secured and correctly installed. The Iridium SIM card is at all times required for operation of the equipment and is a critical and indispensable part of the LT-3100 system. Without a valid Iridium SIM card correctly installed and continuously maintained in the inserted position in the LT-3110 Control Unit, pursuant to the instructions in the LT-3100 User & Installation Manual, the terminal is not operational and not ready and available for continuous use on any vessel.




**Acquire a SIM Card**

An Iridium SIM card must be used for activating a LT-3100 system. The SIM card is described and illustrated in *SIM card (SIM)* on page 25. The SIM card may be acquired directly from your Lars Thrane A/S certified partner. The SIM card must be inserted in the LT-3110 Control Unit before powering up the system.

### Who's My Service Provider

Iridium has a website where they inform about the specific Service Provider (SP) who has activated the LT-3100 system (or any other Iridium activated product).

Use the following link: <https://www.iridium.com/who-is-my-sp/>



The screenshot shows the Iridium website's 'Who's My Service Provider?' page. The header includes the Iridium logo and a navigation menu with links for Company, Careers, Our Legacy, Press, Investors, Blog, Store, and Portal. Below the header, the title 'Who's My Service Provider?' is displayed. The main content area contains a form with a 'Select Type:' label, a dropdown menu for 'ICCID (SIM Card Serial Number)', a text input field with a placeholder '19 digit number starts with 8988, no spaces', and a blue 'Search' button.

Figure 42: Iridium - Who's My Service Provider

You can use the following information:

- ICCID (SIM card serial number)
- MSISDN (Mobile Subscriber ISDN number)

**NOTE:** The Iridium Service Provider (SP) must be contacted for any changes to the provisioning. 'Who's My Service Provider' will inform you where your LT-3100 system is provisioned.

## Change of Hardware and Software

### Change of Hardware

This section will provide some guidance on replacing system units and what the user of the LT-3100 system should be aware of, see Table 18.

| Change of Hardware   |  |   |
|----------------------|--|---|
| Hardware             | Procedure  | Comments  |
| LT-3110 Control Unit | The LT-3110 CU can be replaced by swapping the hardware . Remember the SIM card from the 'old' LT-3110 CU.   | All user data (contacts, call history, and SMS) will be lost, since the LT-3110 CU is the 'master' of the system. |
| LT-3120 Handset      | Change hardware.   | Test the new hardware.  |
| LT-3121 Cradle       |  |   |
| LT-3130 Antenna Unit |  |   |
| SIM Card             | The SIM card can be replaced with a new SIM card, but the Iridium Service Provider must be involved. The ICCID number of the new SIM card must be updated on the provisioning before the new SIM card is inserted in the LT-3110 CU and the system is powered up | Only an Iridium SIM card can be used in the LT-3100 system.   |

Table 18: Change of Hardware in the LT-3100 system

Always remove the DC input power to the LT-3100 system when changing the hardware and system units.

**NOTE:** Changing the LT-3130 Antenna Unit or the SIM card requires involving of the Iridium Service Provider (SP) and provisioning. For details of the Iridium Service Provider (ISP), see *Activating the System* on page 45.

## Software Update

The LT-3100 system must be software updated by using the web server, see *Maintenance, Software update* on page 134. Accessing the web server is described in *Accessing the built-in web server* on page 99. The software update procedure will automatically update all system units connected to the LT-3110 Control Unit. The Lars Thrane Image (LTI-file) e.g. LT-3100-v1.13R-00XX.Iti will include all software components to all system units. All system units connected to the LT-3110 Control Unit will be upgraded or downgraded to be aligned with the LT-3110 Control Unit, which is the 'master' of the system. As soon as the software update procedure is started, the LT-3110 Control Unit window will indicate 'Software update in progress' as illustrated in Figure 43.




Figure 43: Software update

Once the LT-3100 system has finalized the software update, the system will reboot.

**NOTE:** Please check the Lars Thrane A/S company website for newest available software for the LT-3100 system.

## System Services

### Voice call

The LT-3100 system supports Voice call outgoing and incoming from phone numbers (incl. Satcom). Every voice call will generate a record in the Call History placed in the Phone submenu (MENU -> Phone -> Call History), see *Phone* on page 75.

**NOTE:** Verify that the LT-3100 system is ready to make or receive a voice call. Check the network registration status, as illustrated in Table 10 on page 40 (Network Status - Slot 1), which is presenting the signal level and network registration status.

**NOTE:** Always, make sure to have a LT-3120 Handset and LT-3121 Cradle properly installed and connected to the LT-3110 Control Unit. The LT-3110 Control Unit handset connector is illustrated in *Figure 2* on page 6. The LT-3100 system will generate a BAM alert, if the LT-3120 Handset is not connected to the LT-3110 Control Unit (Lost handset).

**NOTE:** The LT-3100 system supports connection of external SIP phones. The connection of external SIP phones is described in *External SIP Phones* on page 61.

The LT-3100 system supports Mobile Originated (MO) outgoing and Mobile Terminated (MT) incoming voice calls. The following sub sections will describe and illustrate the outgoing and incoming voice calls.

### Mobile Originated (MO) - Outgoing

An outgoing voice call can be established as described in Table 19.


| Mode     | Position of Handset                              | Description   |
|----------|--|---|
| on-hook  | Handset placed in cradle until voice established | Type the number and use the off-hook button.  |
|          |  | Use the off-hook button and select the soft key 'Contacts' or 'Call History'. Select the entry and use the off-hook button to initiate the voice call.  |
|          |  | Navigate to Contacts or Call History by using the MENU button (MENU -> Phone -> Contacts or Call History) and use the off-hook button when the entry has been selected. The voice call will now be established. |
| off-hook | Handset lifted out of cradle initially           | Lift the handset out of the cradle (ready tone is available). Type the number and wait 10 seconds or use the # key to initiate the voice call.  |

Table 19: Initiate Mobile Originated (MO) Voice Call

The voice call (on-hook and off-hook mode) will be described and illustrated on the following pages.


On-hook mode:

In on-hook mode the user can either type in the number directly in the display or use the Contacts or Call History to identify the number to be called while the handset is still placed in the cradle. Once the voice call has been established (duration starts to count) the user can lift the handset out of the cradle. The example in this section shows how to use the off-hook button, identifying an entry in the Contacts, and initiate the voice call by pressing the off-hook button.




Press the off-hook button (colored green) on the LT-3110 Control Unit. Hereafter press the soft key 'Contacts'.

Figure 44: Outgoing Voice Call, on-hook mode (1 of 5)




Use the Navigation key and select the contact to be dialed. Press the off-hook button to start connecting the call.

Figure 45: Outgoing Voice Call, on-hook mode (2 of 5)



The LT-3100 system is connecting a voice call to the contact 'Thrane Test' (004529401008).

Figure 46: Outgoing Voice Call, on-hook mode (3 of 5)



The LT-3100 system has established a voice call to 'Thrane Test' (Duration: 00:03).

Figure 47: Outgoing Voice Call, on-hook mode (4 of 5)



The voice call can be terminated by placing the handset in the cradle or use the on-hook button (colored red).


Figure 48: Outgoing Voice Call, on-hook mode (5 of 5)

The mute symbol illustrated in Figure 47 in the status bar will disappear as soon as the handset is lifted out of the cradle. The handset will always be muted when placed in the cradle. The voice from the connected party will be available in the LT-3110 Control Unit speaker, until the handset is lifted out of the cradle. It is always possible to mute and unmute the microphone in the handset from the LT-3110 Control Unit (soft key 'Mute' and 'Unmute') when having an active call and the handset is lifted out of the cradle.

**NOTE:** Adding a new entry in the Contacts (MENU -> Phone -> Contacts) is described and illustrated in *Phone* on page 75.


Off-hook mode:

The off-hook mode can be activated by lifting the handset out of the cradle. In off-hook mode, the user will be met by a *ready tone* and the help text “Please enter number” - hereafter, the called number can be entered, using the numeric keypad. It is not possible to regret, if one or more wrong digits are typed in for the dialed number. In this case, the user must on-hook the phone, and dial the correct number again. The example below shows how to establish the voice call (the other part of the voice call is identical to the on-hook mode described in the previous section).



Lift the handset out of the cradle and a ‘ready tone’ will be available in the handset speaker.

Figure 49: Outgoing Voice Call, off-hook mode (1 of 3)



Type the number in the display by using the numeric keypad (it is not possible to regret).

Figure 50: Outgoing Voice Call, off-hook mode (2 of 3)



Use the off-hook button, # key, or wait 10 seconds for the LT-3100 system to start connecting the voice call.

Figure 51: Outgoing Voice Call, off-hook mode (3 of 3)

**NOTE:** The LT-3100 system will provide the user with information, while connecting and throughout the voice call. In case of problems with the satellite network or connection to the called party (far-end), the user will be informed through a voice prompt, and by status cause codes, that will be presented on the display (e.g. “Temporary link failure”).



Mobile Terminating (MT) - Incoming

The LT-3100 system supports receiving an incoming voice call. The calling party must use the LT- system MSISDN number. The LT-3100 system will check the calling number up against the Contacts entries, if a match exists, the name of the contact will be showed for the incoming voice call.




Incoming voice call available in the LT-3100 system.

Figure 52: Incoming Voice Call (1 of 3)



The handset has been lifted out of the cradle and the voice call is established.


Figure 53: Incoming Voice Call (2 of 3)



The voice call can be muted. To mute/unmute the handset microphone during a voice call, use the soft key 'Mute' and 'Unmute'.


Figure 54: Incoming Voice Call (3 of 3)

An incoming missed voice call is illustrated in the following figures: Figure 55 to Figure 57. By pressing the soft key 'Missed Calls(1)' the user will be redirected to the Call History (filter: Missed Calls). By pressing the soft key 'Show All', all Call History records will be shown (all incoming and outgoing calls).




A missed voice call is illustrated in the display (symbol in status bar and soft key showing 'Missed Calls(1)').

Figure 55: Incoming Voice Call, missed (1 of 3)



By pressing the soft key 'Missed Calls(1)' the user will be directed to the Call History (Missed Calls).

Figure 56: Incoming Voice Call, missed (2 of 3)



Press the soft key 'Show All' and the normal view of the Call History will be shown.

Figure 57: Incoming Voice Call, missed (3 of 3)

**NOTE:** An incoming missed voice call is illustrated in the above figures. By highlighting the missed call in the Call History and press the off-hook button, the LT-3100 system will start establishing a voice call to the party.


**SMS**

The LT-3100 system supports Short Message Service (SMS) sending and receiving from traditional phone numbers (incl. Satcom) and Email addresses.

The LT-3100 system supports sending and receiving concatenating SMS (SMS' consisting of multiple instances). A standard SMS (single instance) consists of 160 characters. If an SMS is sent with a character count >160 characters to a Non-Iridium recipient, the receiving order cannot be guaranteed. If a concatenated SMS is received in the LT-3100 system it will be displayed correctly, even if the character count is >160.

Sending an Email from the LT-3100 system is handled similar to sending a SMS. To insert the Email address in the 'To:' field use the # key to toggle between numbers and letters. If sending an Email to the LT-3100 system, then leave the Subject-field empty. Please note that all text larger than an SMS (160 characters) is truncated and that the length of the Email address + one character is deducted from the payload text. When sending an Email to the LT-3100 system, then the MSISDN number must be used (e.g. 88163XXXXXX@msg.iridium.com). Don't use international prefix ('+' or '00' in front of the MSISDN number).

The SMS Service is located in the Phone submenu (MENU -> Phone -> SMS), as illustrated in Figure 58.



General Messaging (~SMS):  
MENU -> Phone -> SMS


Figure 58: Phone submenu (General Messaging ~SMS)

**NOTE:** The LT-3100 system support SMS sending and receiving from traditionally phone numbers (incl. Satcom) and Email addresses.

**NOTE:** The LT-3100 system can store minimum 500 SMS' in total (sent and received). An individual SMS or SMS conversations can be deleted from the SMS window. To delete all SMS' at once, navigate to the Settings submenu (MENU -> Settings -> Reset Options: Delete SMS Messages).


Sending SMS

To send a SMS, the user of the LT-3100 system must access the Phone submenu (MENU -> Phone -> SMS). In the SMS window all sent and received SMS are visible. In Figure 59 the SMS window is illustrated with 'No Messages'. Press the soft key 'New' to prepare a new SMS. It is possible to reply to an existing conversation (phoner number, Email address) when entries are available. Figure 59 to Figure 65 illustrates sending a new SMS (to a normal phone number).




No SMS' are available in the LT-3100 system (sent or received). Use soft 'New' to prepare a new SMS.

Figure 59: Sending SMS (1 of 7)



Use soft key 'Contacts' or enter the number directly in the To-field.

Figure 60: Sending SMS (2 of 7)




If Contacts has been chosen, then select the contact by using the Navigation key and the soft key 'Select'.

Figure 61: Sending SMS (3 of 7)


**NOTE:** If the Contact has a Phone Number and an Email address the user will need to choose between the two for the message destination.

Press the soft key 'Send' when the destination address and body text have been completed. The SMS service will indicate the transmitting status, which will change from 'Sending' to 'Sent' when the SMS has successfully been sent from the LT-3100 system, see Figure 64 and Figure 65.




Write the SMS text.

Figure 62: Sending SMS (4 of 7)




When the SMS is ready to be sent use the soft key 'Send'.

Figure 63: Sending SMS (5 of 7)



The SMS will change status from Sending to Sent when the SMS has successfully been sent.

Figure 64: Sending SMS (6 of 7)




The SMS has successfully been sent. Otherwise, retry option is available.

Figure 65: Sending SMS (7 of 7)

**NOTE:** If sending the SMS is failing (the SMS window will indicate 'Failed'), then a 'Resend' soft key will be available for the user to make another try. A successful SMS sending will be indicated by 'Sent' - this information will be replaced by 'Now' and hereafter the time since the SMS was successfully sent (e.g. '19 hours ago' and so forth).

Receiving SMS


A received SMS will be indicated by the unread symbol in the status bar, a notification tone, and the soft key 'SMS(1)' will be shown as illustrated in Figure 66.



The LT-3100 system has received a SMS, see symbol in status bar and soft key 'SMS(1)'.


Figure 66: Receiving SMS (1 of 3)

To read the incoming SMS, press the softkey 'SMS(1)' or navigate to the Phone submenu (MENU -> Phone -> SMS). The unread symbol will be removed as soon as the SMS has been read. Open the individual SMS or SMS conversation by pressing the ENTER button. Use the soft key 'Reply' to reply to a sent or received SMS.



Press the soft key 'SMS(1)' and the user will be directed to the SMS window.

Figure 67: Receiving SMS (2 of 3)



Use the ENTER button to open the received SMS.

Figure 68: Receiving SMS (3 of 3)

**NOTE:** The LT-3100 system is handling SMS conversions, which is grouped based on the recipient's address.

**NOTE:** SMS and Email can also be sent from the Web Server, see *Web server, Messages* on page 101.

**External SIP Phones**

The LT-3100 system is supporting connection of external SIP phones, up to 8 external SIP phones. The configuration of the SIP phones must be completed via the web server, see *Telephony* on page 118. Figure 69 is illustrating the connection of the external SIP phones. Connect the SIP phones directly to the LT-3110 Control Unit Ethernet (LAN port).





Figure 69: SIP phones

**NOTE:** The SIP phone might require a DHCP Server to get an IP address assigned. Depending on network setup, it might be needed to configure DHCP Server mode in the LT-3100 system.


The LT-3110 Control Unit UI display (MENU -> System -> SIP Phones) will provide a ‘live’ registration status of the SIP phones configured from the web server.



SIP Phones:  
MENU -> System -> SIP Phones

Figure 70: System Submenu (SIP Phones)

An active voice call to/from a SIP phone will be presented in the Status bar with the symbol showed in Figure 71.



External SIP voice call is using the satellite connection. Can be terminated by using the soft key ‘Terminate Call’.

Figure 71: External SIP Voice Call



By using the soft key 'Terminate Call', the external voice call from the SIP phone will be terminated.

An incoming voice call taken by the SIP phone cannot be forwarded. Once a voice call has been taken by any of the 'lines' the voice call is locked to this user.

The LT-3100 system is supporting local calling between the SIP phones and the LT-3120 Handset. The number plan is illustrated in Table 20. The Caller ID is defined by the user, when configuring the SIP phones.

| LT-3100 system Number Plan (local calls) |              |                 |
|--|--------------|-----------------|
| Number                                   | Caller ID    | Comments        |
| 1000                                     | LT-3100 User | LT-3120 Handset |
| 1100                                     | SIP Phone 1  |                 |
| 1101                                     | SIP Phone 2  |                 |
| 1102                                     | SIP Phone 3  |                 |
| 1103                                     | SIP Phone 4  |                 |
| 1104                                     | SIP Phone 5  |                 |
| 1105                                     | SIP Phone 6  |                 |
| 1106                                     | SIP Phone 7  |                 |
| 1107                                     | SIP Phone 8  |                 |

*Table 20: Number Plan (local calls)*

**NOTE:** The LT-3100 system is only supporting one outgoing satellite voice connection. A local call between two local users will not busy the Satellite voice connection.

## Analogue Phone Adapter

The LT-3100 system is supporting connection of an external Analogue Phone Adapter (e.g. Grandstream). The number of POTS' phones (Plain Old Telephone System), which can be connected to the Analogue Phone Adapter, must be configured as SIP phones in the LT-3100 system, see configuration of SIP phones in *Telephony* on page 118. Connect the SIP phones directly to the LT-3110 Control Unit Ethernet (LAN port).




Figure 72: Analogue Phone Adapter

**NOTE:** The Analogue Phone Adapter might require a DHCP Server to get an IP address assigned. Depending on network setup, it might be needed to configure DHCP Server mode in the LT-3100 system.

The Analogue Phone Adapter (POTS phones) will be handled as SIP phones in the LT-3100 system. Therefore, carefully read the section describing the SIP phones in *External SIP Phones* on page 61.

To provide some guidance for configuration of an Analogue Phone Adapter, the following description will outline some important steps for configuring an Analogue Phone Adapter.

### Configuration of Grandstream HT802 Adapter (example):

If you would like to connect the Analogue Phone Adapter directly to the LT-3100 system, then it might help you to insert a passive switch between the LT-3100 system and the Analogue Phone Adapter, while completing the setup (to allow for an extra LAN port during configuration).

- Step 1: Connect the LT-3100 system, Analogue Phone Adapter, and PC using a passive switch
- Step 2: Login to the LT-3100 system web server. The IP address can be read from the display (MENU -> System -> Network: IP address)
- Step 3: Configure the LT-3100 system to 'DHCP Server' mode (depending on network setup) and configure the SIP phones (Password, and Caller ID)
- Step 4: The Analogue Phone Adapter will now have an IP address assigned. Connect a POTS phone to the Analogue Phone Adapter and use the IVR menu to read out the IP address (off hook handset and type '\*\*\*' followed by '02'). Check the instructions provided for the Analogue Phone Adapter
- Step 5: Log in to the Analogue Phone Adapter and configure FXS PORT 1 and PORT 2 (Primary SIP Server, SIP User ID, Authenticate ID, Password, and Name)
- Step 6: The POTS phones should now be registered and ready to use (the passive switch can be removed)

**Data (Modem Data, SMS and SBD)**

The LT-3100 System is supporting a serial asynchronous automatic dialing and control interface (V250). The interface makes it possible for external equipment (DTE) to use the Iridium 2.4 kbps Modem Data (Direct Internet, RUDICS and SBD) service. Also, the Iridium SMS service is available over this serial interface.

The Modem Data ‘Direct Internet’ service is used for Dial-up Networking, whereas the Modem Data ‘RUDICS’ service is commonly used for Iridium Service Providers e.g. to support Email programs.

The LT-3110 Control Unit offers a virtual serial RS-232 interface (DCE) supporting data, control, and status signals. The serial interface is based on the Telnet Com Port Control Option network protocol (RFC 2217) and is available at the Ethernet (LAN) interface (RJ45 connector).

Access to the serial interface from a PC requires a virtual COM (or tty) port driver supporting RFC 2217 e.g., the Serial Port Redirector (from Fabulatech) on Windows and ttynvt on Mac and Linux. The virtual COM (or tty) port might be used directly by applications running on the PC (e.g., Email applications) or by the operating system to establish a dial-up connection to the Internet (dial-up networking).




Figure 73: LT-3100 system is supporting RFC 2217 (Serial over Ethernet)

The serial interface can be accessed by connecting to the IP address (port 5020) of the LT-3110 Control Unit. The IP address can be read out from the MENU -> System -> Network, see *System Submenus, System* on page 86. The serial interface is by default disabled and must be activated from the built-in web server, see *Web server, Data* on page 117.

**NOTE:** The serial interface (port 5020) must be enabled from the LT-3100 System built-in web server to be available by any external application, see *Web server, Data* on page 117. By default, port 5020 is blocked by the built-in LT-3110 Control Unit Firewall.

The LT-3110 Control Unit display will indicate, if the Modem Data service is active by showing the data symbol in the status bar and the soft key 'Terminate Data', see Figure 74.




Figure 74: Modem Data service active




Figure 75: Modem Data service terminate

By pressing the soft key 'Terminate Data' the user of the LT-3100 system can manually terminate the Modem Data connection. The user of the LT-3100 system must confirm the termination of the Modem Data connection by pressing the soft key 'Yes'.

The LT-3100 system is supporting most of the AT-command set supported by the Iridium 9523N module. The Iridium 9523N AT-commands are available in the Iridium document: ISU AT Command Reference.

| Modem Data Services & Numbers |  |
|-------------------------------|--|
| Service                       | Number   |
| Direct Internet               | 008816000025                                       |
| Direct Internet (Russia)      | 007954107030                                       |
| RUDICS                        | Check with Iridium Service Provider or Application |

Table 21: Iridium Modem Data Numbers

Installation of the Serial Port Redirector (virtual COM port) and Windows Dial-up Networking is further described in the following Lars Thrane A/S LT-3100 Tech Notes, which can be downloaded from our company website:

- LT-3100 Serial Port Redirector Tech Notes
- LT-3100 Windows Dial-up Networking Tech Notes

**IMPORTANT:** If the Modem Data service (Direct Internet) Windows Dial-up Networking is established to provide an IP data connection, then it is important to emphasize that no Firewall protection is supported by the LT-3100 system. Firewall rules must be setup and configured in the PC to provide the required protection.

Email programs

External Email programs can be installed on a PC and use the Serial over Ethernet (RFC 2217) e.g., SPR Virtual COM port to establish a Modem Data connection (RUDICS) to a dedicated RUDICS server. Table 22 list several Email programs and companies, which can be used over an Iridium Modem Data (RUDICS) connection. Additional Email programs may be compatible with the LT-3100 system and the Iridium Modem Data service.

| External Email Programs                |                                 |
|--|---------------------------------|
| SkyFile Mail                           | Marlink                         |
| OnSatMail                              | AST                             |
| GTSeaMail                              | GTMaritime                      |
| SpeedMail                              | SpeedCast                       |
| Iridium Mail & Web (RedPort Optimizer) | Pivotel (Global Marine Network) |

*Table 22: External Email programs*

**NOTE:** It is important to validate the correct Modem Data (RUDICS) Dial-up number with the Iridium Service Provider or the respective company used. Also, make sure that the Modem Data connection is setup with the correct Modem Data service (+CBST - Select Bearer Service Type, default value: 9600 bps V.32). Further details for the AT-command set is available in the Iridium document: ISU AT Command Reference.

**DNS**

The LT-3100 contains a recursive caching DNS server. The DNS server resolves names in the local domain (hostname and DHCP client names), and uses external DNS to resolve names in other domains.

It is possible to use external DNS servers directly (without using the caching DNS server). However, if the firewall is enabled it is recommended always to use the caching DNS server.

**NOTE:** If the firewall is enabled the DNS server only resolves names allowed by the firewall rules

**NOTE:** The DHCP server automatically announces the address of the DNS server. When the LT-3100 is in DHCP client mode or IP static mode, the PC must manually be configured to use the DNS server at the LT-3100

**Outgoing firewall**

The LT-3100 system allows the user to configure the outgoing firewall to only allow specific network traffic. This permits the user to block outgoing network traffic so that IP data is only used for warranted actions. The effect of this action is shown on Figure 76. Setting up the outgoing firewall is described in *Configuration, Network* on page 107.




Figure 76: Outgoing firewall

**PPPoE**

Point-to-Point Protocol over Ethernet (PPPoE) is a link layer network protocol used to facilitate direct communication between two network points. When PPPoE is used in an existing Ethernet/IP network, the PPPoE protocol creates an additional isolated IP network in parallel to the existing Ethernet/IP network. This logical separation of the two IP networks allows the LT-3100 to offer different properties and services on each network and thus also to the clients connected to the respective network. Something similar can be achieved with VLAN, but PPPoE has the additional advantages of being connection oriented and having built-in authentication.

It is important that operating systems like Microsoft Windows can be easily configured **not** to send any data over the PPPoE network, except to/from applications explicitly configured to use the PPPoE network. Because PPPoE is connection oriented, the user can manually Connect/Disconnect from the PPPoE network and thus control data usage directly from the PC. Some applications can even Connect/Disconnect automatically making the use of PPPoE completely transparent.

**NOTE:** To stop data flowing on a PPPoE connection, the PPPoE connection must be disconnected. However, it is also possible to stop the PPPoE connection by using the "Terminate Data" softkey see page 65.

**NOTE:** PPPoE and external model data (see page 64) cannot be activated at the same time.

When configuring PPPoE in the LT-3100, it is optional whether the network traffic shall be routed through the firewall. Avoiding the firewall can be useful in case of trusted applications (e.g. weather or email) or for complete network devices trusted not to misuse the satellite link. The later can be e.g IoT devices or an advanced network router, which can automatically route traffic between the LT-3100 and e.g. other network systems.

**IMPORTANT:** Do not configure the PC to use the PPPoE interface as the default route and simultaneously disable use of firewall.

**NOTE:** The LT-3100 PPPoE uses CHAP for authentication.

**NOTE:** The IP data flowing over the PPPoE link is not encrypted.

**NOTE:** PPPoE is per default disabled and must be activated for use.

**Tracking**

The LT-3100 system is supporting tracking functionality. The periodic tracking functionality must be configured from the LT-3100 system web server, see Configuration - Tracking in *Tracking* on page 121.

The LT-3100 system is supporting the following tracking formats:

| Transport Types & Report Formats |  |
|----------------------------------|--|
| Transport Type                   | Report Format                            |
| SMS                              | Thrane (text)<br>Human readable          |
| Email                            | Thrane (text)<br>Human readable          |
| SBD                              | Thrane (binary)<br>SIRIUS track (binary) |

Table 23: Tracking Transport Types & Report Format

If periodic tracking reports have been configured by the user of the LT-3100 system in the web server, then a tracking symbol will be shown in the status bar of the LT-3110 Control Unit display. Also, this is to inform the user that tracking reports will be sent periodically.




Figure 77: Periodic Tracking Activated

The user of the LT-3100 system can access the Tracking window (MENU -> System -> Tracking) to get some details about the periodic tracking configuration and reports. See Figure 78 on page 70 for the layout of the Tracking window.



The Tracking window shown in Figure 78 illustrates the following periodic tracking configuration:

- Time trigger: Enabled, Timer interval = 12:00 (HH:MM)
- Distance trigger: Enabled, Distance interval = 50.0 (NM), Minimum time interval = 04:00 (HH:MM)




Figure 78: Tracking submenu

Last Report is indicating '1 min ago' because the soft key 'Report Now' button has been used. The soft key 'Report Now' can be used to send additional tracking reports, if tracking has been configured in the web server. Otherwise for this configuration, periodic tracking reports are to be sent every 12 hours / 50 NM (minimum time interval: 4 hours), whatever is first triggered, time or distance.

If Time and/or Distance trigger have been enabled, then Mode is set to Periodic. If none of these trigger conditions have been enabled, then Mode is set to Manual. If the Mode is configured to Manual, then only tracking configuration Options 'Send report on power-on' (configuration parameter from the web server) or the soft key 'Report Now' can activate a tracking report.

If selecting the Last Report using the Navigation key, then you will see the details of this last tracking report sent, as illustrated in Figure 79.




Figure 79: Tracking (Last Report)

**NOTE:** The LT-3100 system supports configuration of periodic tracking reports using different transport types and formats. The periodic tracking reports must be configured using the web server, see Configuration - Tracking in *Tracking* on page 121

Instead of using the periodic tracking report, it is possible without any configuration, to send the vessel position using the Tracking window (MENU -> System -> Tracking). Use the soft key 'Send Position' as illustrated in Figure 78 on page 70.

The LT-3100 system will preformat a position report using the SMS functionality and layout, where the user optionally can select between a regular subscriber number and an Email address. Use the hash '#' key to toggle between numbers and letters in the 'To:' field. It is possible to edit the body text with optional information to the recipient of the vessel position. Whenever the recipient address and body text are completed, use the Navigation key to enter the body text field and the soft key 'Send' will appear. Press the soft key 'Send' and status about transmitting the SMS will be available to the user. The functionality is illustrated in Figure 80 and in Figure 81.




Figure 80: Tracking (Send Position)




Figure 81: Tracking (Send Position)

**NOTE:** The LT-3100 system can send a preformatted message detailing the vessel position from the Tracking window without any preceding configuration. Enter the Tracking window (MENU -> System -> Tracking) and press the soft key 'Send' to activate this functionality and select between regular subscriber number and Email recipient address.

**Bluetooth**

The LT-3100 system offers the user the ability to wirelessly connect equipment to the system using the Bluetooth interface. The Bluetooth feature enables the operator of the system to use the LT-3100 system data connection on their Bluetooth connected equipment. The system currently offers the ability to connect 8 devices simultaneously. The user should consider that connecting 8 devices and accessing data features on all 8 will result in slower data speeds as this divides the LT-3100 download between many devices. Because of this it is advised that the user only connects the needed number of devices.


**NOTE:** The built-in Bluetooth module and functionality will not be available in future production of the LT-3110 Control Unit due to manufacturer shortage and component obsolescence. In the display / GUI (MENU -> Settings -> Bluetooth) it can be verified if the Bluetooth module is mounted or not (the Bluetooth submenu will only be shown if the module is mounted).

**PAN profile**

The Bluetooth connectivity uses a wireless personal area network (WPAN) for connection. This provides data transmission from the LT-3110 Control Unit to Bluetooth connected devices. The connectivity is set up using the PAN profile which makes the Bluetooth network emulate an ethernet connection to connected devices. Applications running on connected devices will see the connection as through ethernet due to this simulation. The PAN profile is currently the only supported Bluetooth profile for the LT-3100 system. Therefore, the Bluetooth functionality is limited to offering a data transmission between the connected device and the LT-3100 system.

**How to pair**

Pairing devices to the LT-3100 using Bluetooth is a straightforward operation. The user must enable Bluetooth on both the LT-3110 Control Unit and the device to pair. Bluetooth is enabled on the LT-3110 Control Unit in the Bluetooth submenu under the Settings menu, this is described in *System Submenus, Settings* on page 79. Figure 82 below shows the Bluetooth submenu with Bluetooth enabled, the system is now ready to pair.




System:  
MENU -> Settings->  
Bluetooth

Figure 82: Bluetooth - How to pair (1 of 5)

**NOTE:** For the LT-3100 to be able to pair to a Bluetooth device, the LT-3110 Control Unit must be in the Bluetooth submenu.


The LT-3100 is chosen from the Bluetooth list on the device which shall be connected. From there a pairing code will be displayed on the LT-3110 Control Unit screen, see Figure 83.



Bluetooth pairing request, press 'Pair' to pair

Figure 83: Bluetooth - How to pair (2 of 5)


The user can now either press 'Pair' to pair with the device or 'Reject' to reject pairing with the device. The 'Pair' softkey is pressed and the device (in this case an iPhone) is connected. The LT-3110 will now display the Bluetooth symbol as displayed on Figure 84.



Bluetooth is enabled and a device is connected

Figure 84: Bluetooth - How to pair (3 of 5)


The connected device (in this case the iPhone) will now be displayed under 'Known Devices' at the bottom of the Bluetooth submenu, this is displayed on Figure 85.



The connected device is shown under 'Known Devices'. Press 'Forget' to remove the device

Figure 85: Bluetooth - How to pair (4 of 5)

To disconnect the device from the LT-3100 the user can either disable Bluetooth on the LT-3110 Control Unit or the paired device or press the 'Forget' softkey. Using the 'Forget' softkey will remove the device from the list as seen on Figure 86.



The device has been disconnected and forgotten


Figure 86: Bluetooth - How to pair (5 of 5)

## System Submenus

This section describes and illustrates the submenus Phone, Settings, and System. The submenus are accessed by pressing the MENU button.

### Phone

The Phone submenu contains the following entries: Contacts, SMS, Call History, Data History and Phone Usage. See Figure 87 for the layout of the Phone submenu.




SIP Phones:  
MENU -> Phone

Figure 87: Phone submenu

### Contacts

The Contacts provides a list of contacts created by the user. Create a new contact by pressing the soft key 'New' and add phone number and/or Email and name. The phone number is limited to numbers (e.g. 004529401008). The Contact list can contain 100 contacts. Use international number prefix, either '+' or '00XX' in front of the number. A contact can be deleted from the list by pressing the soft key 'Delete' and confirm this.



Contacts:  
MENU -> Phone ->  
Contacts

Figure 88: Phone submenu (Contacts)

**NOTE:** The user can select an entry from the Contacts (e.g. Thrane Test) and use the Off-hook button to establish a voice call to the contact, if the Contact has a registered phone number.

**NOTE:** The user must define a Name for the contact but can input both Phone number and Email address or either of the two.





Figure 89: Contacts (New Contact)

SMS

The SMS Service is described and illustrated in SMS on page 56.

Call History

The Call History provides a complete list of all voice calls: outgoing, incoming, and missed calls, as illustrated in Figure 90. 'Unknown' entries in the Call History will show the soft key 'New Contact' to help creating the 'Unknown' contacts in the Contact list. Use the soft key 'Show Missed' to filter for incoming missed calls.




Call History:  
MENU -> Phone -> Call History

Figure 90: Phone submenu (Call History)

Data History

The Data History provides a complete list of all Modem Data connections outgoing and incoming connections will be listed. The Data History is illustrated in Figure 91. The Modem Data is further described in *Data (Modem Data, SMS and SBD) on page 64.*




Data History:  
MENU -> Phone -> Data History

Figure 91: Phone submenu (Data History)

Phone Usage

The Phone Usage lists Trip and Lifetime user terminal usage. The list includes voice totals for incoming and outgoing voice calls, data incoming and outgoing and SBD sent and received. To switch between Trip and Lifetime usage, press the softkey titled 'Show Lifetime/Trip' This includes Voice totals, SMS totals, Data totals and SBD totals as illustrated in Figure 92 to Figure 95



Phone Usage:  
MENU -> Phone -> Phone Usage (Trip usage)

Figure 92: Phone submenu (Phone Usage)




Figure 93: Phone submenu (Phone Usage)



UTC: 2021-02-16 08:19  
POSN: 55°49.153N 012°29.290E

📶

| Lifetime Usage |         |
|----------------|---------|
| Voice Total    | 0:03:24 |
| Voice Outgoing | 0:03:24 |
| Voice Incoming | 0:00:00 |
| SMS Sent       | 1       |
| SMS Received   | 10      |

Show Trip

Phone Usage:  
MENU -> Phone -> Phone  
Usage  
(Lifetime usage)

Figure 94: Phone submenu (Phone Usage)

UTC: 2021-02-16 08:19  
POSN: 55°49.153N 012°29.290E

📶


| Lifetime Usage |                    |
|----------------|--------------------|
| Data Total     | 0:00:00 / 0.000 kB |
| Data Outgoing  | 0:00:00 / 0.000 kB |
| Data Incoming  | 0:00:00 / 0.000 kB |
| SBD Sent       | 0 / 0.000 kB       |
| SBD Received   | 0 / 0.000 kB       |

Show Trip

Figure 95: Phone submenu (Phone Usage)


### Settings

The Settings submenu contains the following entries: Audio, Display, Date & Time, Phone Setup, Bluetooth, Security and Reset Options. See Figure 96 and Figure 97 for the layout of the Settings submenu.



Settings:  
MENU -> Settings  
(upper view)

Figure 96: Settings submenu




Settings:  
MENU -> Settings  
(lower view)

Figure 97: Settings submenu

Audio


The Audio settings handle all audio levels and notifications. Here is a short description of the audio settings and their functionality in the LT-3100 system (see Figure 98 for layout):

- *Speaker Volume* adjusts the output level of the LT-3110 Control Unit speaker (located below the Brightness button). The Speaker Volume setting is primarily used when operating the system with the LT-3120 Handset placed in LT-3121 Cradle (e.g. making a voice call). The Navigation key (arrows up/down) can be used to control the Speaker Volume output level, when audio is directed to control unit speaker.
- *Handset Volume* adjusts the output level of the LT-3120 Handset speaker (user audio). The user can adjust the Handset Volume during a voice call by using the LT-3120 Handset volume button (up/down) on the side of the handset.
- *Ringer Volume* adjusts the output level of the ringer, when an incoming voice call is presented in the LT-3100 system. The Ringer output will be directed to the LT-3120 Handset (integrated ringer speaker on the back side) when placed in the LT-3121 Cradle. Otherwise, the LT-3110 Control Unit speaker is used for indicating an incoming voice call.
- *Key Beep* adjusts the output level of the audio feedback when using the LT-3110 Control Unit keypad. Can be configured to 'Off' if desired.



Audio:  
MENU -> Settings ->  
Audio

Figure 98: Settings submenu (Audio)




Notifications:  
MENU -> Settings ->  
Audio -> Notifications

Figure 99: Settings Submenu (Notifications)

**NOTE:** Audio notifications can be disabled for SMS. The unread symbol in the status bar will still be shown, if audio notifications are disabled.

Display

The Display settings handles all display settings: mode (day or night time) and brightness.




Display:  
MENU -> Settings ->  
Display

Figure 100: Settings submenu (Display)

**NOTE:** The display settings can also be configured using the ‘Brightness’ button. Short press on the ‘Brightness’ button changes the brightness, whereas long press on the ‘Brightness’ button changes between day and night time.

Date & Time

Date & Time settings provides the user with a possibility to change formats after completing the Installation Wizard. The LT-3100 system supports the following date formats: YYYY-MM-DD, D MMM YYYY, DD/MM/YYYY, and MM/DD/YYYY. The time format can be configured to either 24 or 12 hours.




Date & Time:  
MENU -> Settings -> Date  
& Time

Figure 101: Settings submenu (Date & Time)

Phone Setup

Phone Setup provides the user with phone numbers to the Voicemail and to the SMS Service Center. This is illustrated on Figure 102 . Note that these numbers are not dialable from this menu.




Phone Setup:  
MENU -> Settings ->  
Phone Setup

Figure 102: Settings submenu (Phone Setup)

Bluetooth

The Bluetooth submenu offers the user the ability to wirelessly connect devices to the LT-3100 using Bluetooth. How to setup this connection is described in *Bluetooth, How to pair* on page 72.



Phone Setup:  
MENU -> Settings ->  
Bluetooth

Figure 103: Settings submenu (Bluetooth)





Figure 104: Settings submenu (Bluetooth)


Security

The security submenu allows the user to configure settings regarding SIM Lock and changing the SIM PIN code, this is illustrated on Figure 105. To Enable SIM Lock the SIM PIN code is required, as seen on Figure 106.



Phone Setup:  
MENU -> Settings ->  
Security


Figure 105: Settings submenu (Security)



SIM PIN is required to  
enable SIM Lock


Figure 106: Settings submenu (Security)

To change the SIM PIN the user is required to input the current SIM PIN and then select a new SIM PIN. The New SIM PIN must be repeated before it is confirmed. See Figure 107 to Figure 109 for an illustration of this process.




To change SIM PIN the  
current SIM PIN is  
required

Figure 107: Settings submenu (Security)



A new SIM PIN is entered

Figure 108: Settings submenu (Security)



The new 4 digit SIM PIN must be repeated


Figure 109: Settings submenu (Security)

**NOTE:** To change SIM PIN the SIM Lock feature has to be enabled.

**NOTE:** There is a minimum requirement of four digits for new SIM PIN's. There is however no max limit of digits.


Reset Options

The Reset Options handles the reset of the following user records and configurations: Call History, SMS, and Web Server Authentication. Use the soft key 'Execute' or the 'ENTER' button to activate the reset, when the correct Reset Option has been selected by the 'Navigation' key (arrow up/down). The user of the LT-3100 system will have to confirm the reset, see Figure 110 and Figure 111.



Phone Setup:  
MENU -> Settings ->  
Reset Options

Figure 110: Settings submenu (Reset Options)



The user must confirm the reset to clear the selected data from memory


Figure 111: Settings submenu (Reset Options)

**NOTE:** The reset of the web server authentication can be managed from the Settings submenu for the user to get access to the web server in the situation where the user cannot find the changed password. To avoid unwanted access to the web server via the network interface, it is highly recommended to change the web server authentication password at any time. The web server authentication is described and illustrated in *Authentication* on page 104.




**System**

The System submenu contains the following entries: BAM Alert, Network, Tracking, SIP Phones, Position Status, System Info, and Power Supply. See Figure 112 and Figure 113 for the layout of the System submenu.



System:  
MENU -> System  
(upper view)

Figure 112: System submenu




System:  
MENU -> System  
(lower view)

Figure 113: System submenu

BAM Alerts


BAM Alerts provides an overview of the active alerts in the LT-3100 system. The Bridge Alert Management (BAM) is described and illustrated in detail in *Bridge Alert Management (BAM)* on page 91.



BAM Alerts:  
MENU -> System -> BAM  
Alerts (or long press on  
the MENU button)


Figure 114: System submenu (BAM Alerts)

**NOTE:** The BAM Alerts list illustrated in Figure 114 should under normal conditions be empty (No Alerts). Make sure to read the alerts carefully and take appropriate action.




BAM alert shown in the status bar (active warning). The blue dot indicates a change in the BAM Alerts, after the user has last been in the list.

Figure 115: BAM Alerts (1 of 4)




Long press on the MENU button to access the BAM Alerts (Lost Handset).

Figure 116: BAM Alerts (2 of 4)



Press the soft key 'Silence All' to mute the audible alarm for 30 seconds.

Figure 117: BAM Alerts (3 of 4)




Press the soft key 'ACK Alert' acknowledge the BAM alert.

Figure 118: BAM Alerts (4 of 4)

Network

The Network provides an overview for the user of the LT-3100 system of the IP network configuration and setup. The LT-3100 system can be configured to: DHCP Client, DHCP Server, and Static IP address. The link status will provide the user with information about and whether an IP connection is established to the LT-3110 Control Unit. The IP address of the LT-3110 Control Unit is provided under the IP Address parameter illustrated in Figure 119.



Network:  
MENU -> System ->  
Network

Figure 119: System submenu (Network)

**NOTE:** Use the IP Address to access the built-in web server. Instructions to access the built-in web server is provided in *Accessing the built-in web server* on page 99.

Tracking


The Tracking functionality is described and illustrated in *Tracking* on page 69.

SIP Phones

The SIP Phones functionality is described and illustrated in *External SIP Phones* on page 61.


GNSS Status

The Position Status provides an overview for the user of the LT-3100 system built-in GNSS receiver. The GNSS receiver can be configured from the web server, see *GNSS and BAM* on page 128.



GNSS Status:  
MENU -> System -> GNSS  
Status  
(upper view)

Figure 120: System submenu (GNSS Status)




GNSS Status:  
MENU -> System -> GNSS  
Status  
(lower view)

Figure 121: System submenu (GNSS Status)

**NOTE:** The GNSS Status window shows the GNSS receiver status (in Automatic GNSS mode). The Manual Position input will not be shown in the Position Status window. The Position Status (Automatic GNSS) integrity states are further described and illustrated in *App. F - GNSS Receiver Integrity States* on page 146.


System Info

The System Info provides details about the LT-3100 system software and hardware. In addition, the following numbers are available: MSISDN (~satellite phone number), IMEI (~mobile equipment number), and ICCID (~SIM card number). The System Info is illustrated in Figure 122 and in Figure 123.



System Info:  
MENU -> System -> System Info  
(upper view)

Figure 122: System Submenu (System Info)



System Info:  
MENU -> System -> System Info  
(lower view)

Figure 123: System submenu (System Info)

Power Supply

The Power Supply provides details about the DC input voltage on the LT-3110 Control Unit and LT-3130 Antenna Unit.




Figure 124: System submenu (Power Supply)

## Bridge Alert Management (BAM)

Bridge Alert Management (BAM) is the IMO defined overall concept for the harmonized management, distribution, handling and presentation of alerts on the bridge, to enable the bridge team to devote full attention to the safe operation of the ship and to immediately identify any alert situation requiring action to maintain the safe operation of the ship. The LT-3110 system implements the BAM concept in compliance with the relevant standards (IEC 62923-1 and IEC 62923-2 Bridge Alert Management).

### BAM status

The LT-3100 system continuously monitors for fault conditions (e.g. no satellite signal), that requires the attention of the bridge team and raises relevant alerts. The user can, at any time, check for the presence of alerts without performing any action: if there are one or more active alerts, a BAM icon representing the alert with the highest priority is shown in the status bar (see Figure 125). The exact icon shown depends on the priority and state of the alert with the highest priority (see Table 24 on page 92). It is not possible to hide or suppress the BAM icon in the status bar.




Figure 125: LT-3110 Control Unit (BAM status)

### Alert list

Once the user has become aware an alert has been raised, the user can navigate to the alert list (MENU -> System -> BAM Alerts) to find further information about the alert conditions.

**NOTE:** For quick access to the alert list, long press (≥ 1 s) the MENU button at any time.



The BAM Alerts window will list the current unacknowledged and acknowledged alerts.

Figure 126: LT-3110 Control Unit (BAM Alert list)

See *App. B - Bridge Alert Management (BAM)* on page 138 for the full list of alerts that can be raised by the LT-3100 system.

Alert priority and state

The *priority* of an alert indicates its severity. The BAM concept defines 4 priorities: Emergency Alarm, Alarm, Warning and Caution. The LT-3100 system can raise alerts of the following priorities:

- **Warning:** Condition requiring immediate attention, but no immediate action by the bridge team. Warnings are presented for precautionary reasons to make the bridge team aware of changed conditions which are not immediately hazardous but may become so if no action is taken.
- **Caution:** Lowest priority of an alert. Awareness of a condition which does not warrant an alarm or warning condition, but still requires attention out of the ordinary consideration of the situation or of given information.

The shape and color of the BAM icon indicates the priority of the alert and the symbol inside indicates its state as per Table 24 below.







| BAM Alert Icons, Priority and Stat |   |                                     |  |                |
|------------------------------------|---|-------------------------------------|--|----------------|
| Priority                           | Icon  | State                               | Condition  | Audible signal |
| Warning                            |    | Active – unacknowledged             | Alert condition present.<br>Alert not acknowledged.  | Yes            |
|                                    |  | Active – silenced                   | Alert condition present.<br>Alert not acknowledged, but audible signal has been silenced by the operator.              | No             |
|                                    |  | Active – acknowledged               | Alert condition present.<br>Alert acknowledged by the operator.  | No             |
|                                    |  | Active – responsibility transferred | Alert condition present.<br>A function of the BAM compliant equipment with additional system knowledge has taken over. | No             |
|                                    |  | Rectified – unacknowledged          | Alert condition rectified.<br>Alert still unacknowledged.  | No             |
|                                    | None  | Normal                              | No alert condition present.  | No             |
| Caution                            |  | Active                              | Alert condition present.   | No             |
|                                    | None  | Normal                              | No alert condition present.  | No             |

Table 24: BAM Alert Icons, Priority and State

### Temporary silence

Active unacknowledged alerts cause a short but periodically repeated audible signal. To temporarily silence all alerts (and thus the audible signal), press the “Silence All” soft key. The temporary silence period expires after 30 s, after which active silenced alerts become active unacknowledged alerts again, causing the audible signal to resume.




Figure 127: LT-3100 Control Unit (BAM Alerts)

**NOTE:** Active unacknowledged alerts cause a short but periodically repeated audible signal, which can be temporary silences (30 s) by pressing the soft key ‘Silence All’. This temporary silence has been illustrated in Figure 127.

### Alert acknowledgement

Alerts of priority warning must be acknowledged by the user. To acknowledge an alert, press the “ACK Alert” soft key.

Some alerts cannot be acknowledged by the user, in which case the “ACK Alert” soft key will be absent. This applies to alerts for which the alert text and alert description is not enough for decision support.

When an alert is both acknowledged and rectified it disappears from the alert list. Cautions cannot be acknowledged and thus disappear as soon as they are rectified.

### Aggregation

The BAM concept defines aggregation as a means for an alert source to combine multiple individual alerts of the same kind into a single aggregated header alert in order to help reduce the risk that the number of individual alerts obscures the display of equally important additional alerts, for example due to the active alert list length exceeding the maximum display capability of the alert source UI.

**NOTE:** The LT-3100 system currently does not define any alerts that can be aggregated.



### Responsibility transfer

The BAM concept defines the Central Alert Management (CAM) system as equipment used for centralizing management, handling and presentation of alerts on the bridge. A CAM system may be standalone or combined with other equipment, for example in the case of an Integrated Navigation System (INS).

A CAM system connects to multiple alert sources (such as the LT-3100 system) in order to manage and present their alerts on the CAM UI. An alert will thus be presented in the alert list of both the alert source and the CAM system.

To reduce the number of high-priority audible alerts for one situation that requires attention, if the CAM system has additional knowledge regarding an alert situation, which caused the LT-3100 system to raise an alert, the CAM system may apply responsibility transfer and raising a new alert with, if practicable, a lower priority.

**NOTE:** Alerts of priority caution are not audible and therefore cannot have their responsibility transferred.

**NOTE:** The LT-3100 will reject the request for responsibility transfer if no HBT sentence (indicating good status) has been received from the CAM system within the last 90 s.

The alert text and alert description of an alert is presented on the CAM system. For some alerts, additional information must be presented in order to allow user acknowledgement of the alert. Responsibility transfer is not allowed for such alerts as they can only be acknowledged at the alert source, where the additional information is present.

### Time synchronization

The LT-3100 system can supply the UTC time of alert state changes to the CAM system due to the built-in GNSS receiver.

**NOTE:** If the alert state change occurs before the built-in GNSS receiver has obtained the UTC time or in case of GNSS receiver malfunctioning, the LT-3100 system will not supply the UTC time.

## Serial Interface (RS-422)

### GNSS sentences

The LT-3100 system supports outputting of GNSS sentences encoded as NMEA 0183 via an RS-422 interface from the LT-3100 system, as illustrated in Figure 128. The LT-3100 system has a built-in GNSS receiver in the LT-3130 Antenna Unit.




Figure 128: GNSS sentences

Table 25 presents the supported GNSS sentences by the LT-3100 system. The configuration of the GNSS sentences are illustrated and described in *GNSS and BAM* on page 128.

| GNSS Sentences |           |       |        |
|----------------|-----------|-------|--------|
| Sentence       | Baud Rate |       |        |
|                | 4.800     | 9.600 | 38.400 |
| DTM            | X         | X     | X      |
| GGA            | X         | X     | X      |
| GLL            | X         | X     | X      |
| GSA            | X         | X     | X      |
| GSV            | -         | X     | X      |
| RMC            | X         | X     | X      |
| VTG            | X         | X     | X      |
| ZDA            | X         | X     | X      |

Table 25: GNSS sentences

**IMPORTANT:** The GNSS receiver of the LT-3100 system is not certified according to IMO performance standards for GNSS receivers. The LT-3100 system shall not be connected to equipment where the GNSS receiver interface must be certified.

The GNSS sentences and decoding of these are further documented in *App. D - GNSS sentences* on page 144.

**BAM sentences**

The LT-3100 system supports connection to an external Central Alert Management (CAM) system via an RS-422 interface from the LT-3100 system, as illustrated in Figure 129. The CAM system can receive BAM information (e.g. warning and cautions) from the bridge equipment and centralize and present this information to the user, which can be acknowledged to the BAM equipment (here the LT-3100 system).




Figure 129: CAM/BAM system

Table 26 presents the supported BAM sentences by the LT-3100 system. The configuration of the BAM sentences is illustrated and described in *GNSS and BAM* on page 128.

| Sentences Received by SES    |                   |  |
|------------------------------|-------------------|--|
| Sentence                     | Name              | Comment                                      |
| ACN                          | Alert Command     | Alert command for instance acknowledge       |
| HBT                          | Heartbeat         | Support reliable alert related communication |
| Sentences Transmitted by SES |                   |  |
| Sentence                     | Name              | Comment                                      |
| ARC, ALC, ALF                | Alert information |  |

Table 26: BAM sentences

**NOTE:** The encoding of BAM sentences is defined in IEC 61162-1 (Edition 5.0, 2016-08), the encoding is similar to NMEA 0183.

The BAM sentences and decoding of these are further documented in *App. E - BAM Sentences* on page 145.

## NMEA 0183 over UDP

The LT-3100 system is supporting transmission of NMEA 0183 sentences (GNSS position information) via the LAN or Bluetooth interface. The supported protocol is UDP (only broadcast).




Figure 130: NMEA 0183 over UDP (broadcast)

The IP destination address will always be the local broadcast address of the LAN or BT network. I.e., if the configured LAN network address/mask is 192.168.1.0/24 the destination address will be 192.168.1.255.

The UDP destination port is user configurable, see Table 27.

| UDP broadcast Port Configuration |             |
|----------------------------------|-------------|
| Interface                        | Port Number |
| LAN                              | 1 to 65535  |
| Bluetooth                        | 1 to 65535  |

Table 27: UDP Broadcast Port Configuration

The configuration of the NMEA 0183 over UDP is illustrated in section *GNSS and BAM* on page 128. The Talker ID of the NMEA 0183 sentences can be changed by changing the configuration of the GNSS Receiver.

**NOTE:** Currently it is only possible to send NMEA 0183 sentences (GNSS position information) on one interface at a time. I.e., selecting CU LAN will disable GNSS on the RS-422 interface and vice versa.

## Web server

The LT-3110 Control Unit has a built-in webserver, which can be accessed from the Ethernet (RJ45) interface from the back side of the control unit. A PC must be connected to the control unit, either directly by connecting an Ethernet cable between a PC and the LT-3110 Control Unit, or by connecting the LT-3110 Control Unit to a Local Area Network (LAN), to where the PC is connected.

**NOTE:** The IP address allocated to the LT-3110 Control Unit, is shown in the GUI (Menu -> System -> Network: IP Address).

The screenshot displays the LT-3100 System web server dashboard. On the left is a navigation menu with options: Dashboard, Messages, Configuration, Maintenance, Legal notice, Log out, and Disable login timeout. The main content area is divided into several sections:

- System Information:**
  - System Number: LT-3100
  - Software Version: v1.15R-0003
  - IMEI: 300125060699550
  - ICCID: 8988169310000008589
- System Units:**

| Number  | Name         | Status    |
|---------|--------------|-----------|
| LT-3110 | Control Unit | Connected |
| LT-3130 | Antenna Unit | Connected |
- Telephony:**
  - Outgoing Lines:**

| Line | Type | Number  | Status |
|------|------|---------|--------|
| 1    | -    | Unknown | Idle   |
  - Phones:**

| Number | Caller ID | Status       |
|--------|-----------|--------------|
| 1000   | Handset   | Idle         |
| 1100   | SIP 1     | Unregistered |
| 1101   | SIP 2     | Unregistered |
| 1102   | SIP 3     | Unregistered |
- Data:**
  - Satellite Data Services:**

| Name             | Status | Rx       | Tx       |
|------------------|--------|----------|----------|
| Iridium Internet | Down   | 0.005 MB | 0.003 MB |
| Modem Data       | Down   | 0.005 MB | 0.003 MB |
  - Local Interfaces:**

| Interface | Protocol  | Service    | Firewall | Status   |
|-----------|-----------|------------|----------|----------|
| LAN       | IP/serial | Modem Data | N/A      | Stopped  |
| Bluetooth | IP/serial | Modem Data | N/A      | Disabled |
- BAM:** No active alerts.

Figure 131: Web server (System dashboard)

The functionality of all web pages is described in further detail in the following sections. Some of the sections will refer to other sections in this User & Installation Manual, e.g. hardware interfaces.

**NOTE:** All web pages functionality will be described in detail for the LT-3100 system. It is the intention that the web pages should be used during the installation and configuration of the system. During normal operation of the system, it shouldn't be necessary to access the web pages.

## Accessing the built-in web server

To access the built-in web server of the LT-3100 system, please complete the following steps:

1. Connect the LT-3110 Control Unit directly to a PC using an Ethernet cable or connect the LT-3110 Control Unit to a Local Area Network (LAN), where a PC is connected.
2. Identify the IP address that is assigned to the LT-3110 Control Unit. The IP address can be read out from the display (MENU -> System -> Network: IP Address). The IP address is valid if the 'Link Status' is showing 'Up'. The IP address is assigned dynamically by a DHCP server.
3. From the PC, start a browser (e.g. Microsoft Edge, Explorer, Chrome, etc.) and type in the IP address, which was identified in the LT-3110 Control Unit (e.g. 10.1.10.39).
4. The browser might show you a warning about an invalid web server certificate, as illustrated in Figure 132. Make sure, that you have typed in the correct IP address.
5. Press 'Details' and you will be presented for an extended page view (including a link), which will direct you to the LT-3100 system dashboard 'Go on to the webpage (Not recommended)'.  
6. You will now see the LT-3100 system dashboard.




Figure 132: Accessing the built-in web server ("This site is not secure").

### Dashboard

The dashboard is showing details about the two main units, which forms the Satcom system: the LT-3110 Control Unit and the LT-3130 Antenna Unit. If the antenna unit is connected properly to the control unit, then the antenna unit will be visible on the web server dashboard, as illustrated in Figure 133. Otherwise only the control unit will be visible. For each unit, the following information will be available: unit number, unit name, unit part number, unit serial number, and software version. The antenna unit will automatically be updated with the software version, which is available in the control unit.




Figure 133: LT-3110 Control Unit - built-in web server (dashboard).

The web server has the following web pages:

- Dashboard
- Messages
- Configuration
- Maintenance
- Legal notice
- Log out
- Disable login timeout

## Messages

### Email

The LT-3100 system is supporting Email which is described in *SMS* on page 56. The LT-3100 system is offering the ability to read compose and send Email via the web server as illustrated in Figure 134. By clicking on the individual Email the message will expand and the user can read the content of the message. Reading an Email on the Web server clears the SMS notification on the LT-3110 Control Unit




Figure 134: Web server (Email)

To compose an Email either click the “Compose Email” field or reply to a specific Email by clicking the “Reply” arrow next to the Email. To compose an Email input the receiving Email address and the Email text. When sending Email over 160 characters, the message is split into several SMS resulting in a higher end user cost. The maximum size is 6 SMS’ this is illustrated Figure 135.




Figure 135: Web server (Email)



**SMS**

The LT-3100 system is supporting short message service (SMS), which is described in *SMS* on page 56. The LT-3100 system is offering the ability to read compose and send SMS via the web server as illustrated in Figure 136. By clicking on the individual SMS the message will expand and the user can read the content of the message. Reading an SMS on the Web server clears the SMS notification on the LT-3110 Control Unit.




Figure 136: Web server (SMS)

To compose an SMS either click the “Compose SMS” field or reply to a specific SMS by clicking the “Reply” arrow next to the SMS. To compose an SMS input the receiving phone number and the SMS text. When sending large SMS, the message is split into several SMS resulting in a higher end user cost. The maximum size is 6 SMS. This is illustrated on Figure 137.




Figure 137: Web server (SMS)

**NOTE:** The SMS text can be 160 characters long. This includes spaces, symbols, letters, and paragraph changes.

**NOTE:** For both SMS and Email it is possible to input a Contact in the ‘To’ field. This requires the contact to have a valid phone number and/or Email.

### Configuration

After installation of the LT-3100 system has been properly performed, the system is fully operational. In this section there will be a description of system settings which are configurable from the Web Server.

Under Configuration, the following webpages are available:

The screenshot displays the 'LT-3100 System' web interface. On the left is a navigation menu with options: Dashboard, Messages, Configuration (expanded), Authentication, Network, Bluetooth, Data, Telephony, Contacts, Tracking, External I/O, GNSS and BAM, Reset, Maintenance, Legal notice, Log out, and Disable login timeout. The main content area shows:

- System Information:** System Number (LT-3100), Software Version (v1.15R-0003), IMEI (300125060699550), ICCID (8988169310000008589).
- System Units:**

| Number  | Name         | Status    |
|---------|--------------|-----------|
| LT-3110 | Control Unit | Connected |
| LT-3130 | Antenna Unit | Connected |
- Telephony:**
  - Outgoing Lines:**

| Line | Type | Number  | Status |
|------|------|---------|--------|
| 1    | -    | Unknown | Idle   |
  - Phones:**

| Number | Caller ID | Status       |
|--------|-----------|--------------|
| 1000   | Handset   | Idle         |
| 1100   | SIP 1     | Unregistered |
| 1101   | SIP 2     | Unregistered |
| 1102   | SIP 3     | Unregistered |
- Data:**
  - Satellite Data Services:**

| Name             | Status | Rx       | Tx       |
|------------------|--------|----------|----------|
| Iridium Internet | Down   | 0.005 MB | 0.003 MB |
| Modem Data       | Down   | 0.005 MB | 0.003 MB |
  - Local Interfaces:**

| Interface | Protocol  | Service    | Firewall | Status   |
|-----------|-----------|------------|----------|----------|
| LAN       | IP/serial | Modem Data | N/A      | Stopped  |
| Bluetooth | IP/serial | Modem Data | N/A      | Disabled |

At the bottom, there is a 'BAM' section with the text 'No active alerts'.

Figure 138: Web server (Configuration)

- Authentication
- Network
- Bluetooth
- Data
- Telephony
- Contacts
- Tracking
- External I/O
- GNSS and BAM
- Reset

**Authentication**

The LT-3100 system supports configuration of authentication on the web server.

The default password for the User = admin is Password = admin. The LT-3100 system will always be delivered from the factory with this default password.

**NOTE:** It is recommended that the user of the LT-3100 system changes the default password during the installation of the system, so that a random user on the network do not have access to the web server.




Figure 139: Web server - Authentication

If the authentication password is changed from default and forgotten, then the authentication password can be reset from the display (MENU -> Settings -> Reset Options: Reset Web Authentication). Remember to change the authentication password away from the default password as soon as it has been possible to re-enter the web server. The Reset Web Authentication is further described and illustrated in *Settings* on page 79.

User login

The LT-3100 system supports configuration of a separate web server login named User for the purpose of reading and sending SMS and Email. The User profile is also able to download the diagnostics file. The operator needs to login using the Admin profile to set a password for the User profile, this is displayed on Figure 140.




Figure 140: Web server (User login)

After setting the User profile password using the Admin profile, the User profile can be accessed. When logging in using the User profile, only the SMS and Email tabs will be available. From here SMS and Email can be sent and read this is displayed in Figure 141 on page 106.

**LT-3100 System**

- Dashboard
- Messages ▼
- Configuration ▼
- Maintenance ▼
- Legal notice
- Log out
- Disable login timeout

UTC: 15 May 2023 08:40:36  
 POSN: 55°49.152N 12°29.290E

**System Information**

|                  |                     |
|------------------|---------------------|
| System Number    | LT-3100             |
| Software Version | v1.15R-0003         |
| IMEI             | 300125060699550     |
| ICCID            | 8988169310000008589 |

**System Units**

| Number  | Name         | Status                   |
|---------|--------------|--------------------------|
| LT-3110 | Control Unit | Connected <span>▼</span> |
| LT-3130 | Antenna Unit | Connected <span>▼</span> |

**Telephony**

Outgoing Lines

| Line | Type | Number  | Status |
|------|------|---------|--------|
| 1    | -    | Unknown | Idle   |

Phones

| Number | Caller ID | Status       |
|--------|-----------|--------------|
| 1000   | Handset   | Idle         |
| 1100   | SIP 1     | Unregistered |
| 1101   | SIP 2     | Unregistered |
| 1102   | SIP 3     | Unregistered |

**Data**

Satellite Data Services

| Name             | Status | Rx       | Tx       |
|------------------|--------|----------|----------|
| Iridium Internet | Down   | 0.005 MB | 0.003 MB |
| Modem Data       | Down   | 0.005 MB | 0.003 MB |

Local Interfaces

| Interface | Protocol  | Service    | Firewall | Status   |
|-----------|-----------|------------|----------|----------|
| LAN       | IP/serial | Modem Data | N/A      | Stopped  |
| Bluetooth | IP/serial | Modem Data | N/A      | Disabled |

**BAM**

No active alerts

Figure 141: Web server (User login)

**NOTE:** It is recommended that the installer of the LT-3100 system sets the User profile password during the installation of the system. It is highly recommended to keep the User profile password different from the admin profile password.

**Network**

The LT-3100 system is supporting the most common network configurations for Local Area Network (LAN). The LT-3100 system has one Ethernet (RJ45) interface, which is described in *Ethernet RJ45 (LAN)* on page 26.

The following network configuration modes will be described in this section:

- DHCP client
- DHCP server
- Static

The default network configuration mode for the Ethernet interface is DHCP client.




Figure 142: Web server - Network

**NOTE:** In DHCP client mode, Link-local is supported, in order to connect another ‘passive’ IP-device (e.g. a PC) directly to the LT-3110 Control Unit. Expect the LT-3110 Control Unit to get the IP-address: 169.254.1.1.

**NOTE:** The IP-address of the LT-3110 Control Unit is always displayed in the UI (MENU -> System -> Network), see details in *System* on page 86




Figure 143: Web server - Network

If the LT-3100 system is connected to a local network as illustrated in Figure 143, where a DHCP server is already available, then the LT-3100 system must be configured to either DHCP client or Static mode. The Static mode can be used, if it is required that the IP-address of the LT-3110 Control Unit must never change.

The LT-3100 system has two reserved network ranges, which are documented in Table 28.

| Reserved Network Ranges |              |
|-------------------------|--------------|
| Sub-net                 | Function     |
| 172.27.0.0/16           | Internal use |
| 192.168.110.0/23        | PPPoE        |
| 192.168.111.0/23        | PPPoE        |
| 192.168.112.0/23        | PPPoE        |
| 192.168.254.0/24        | PPPoE        |
| 192.168.255.0/24        | Bluetooth    |

Table 28: Reserved Network Ranges

**IMPORTANT:** Do not connect the LT-3100 System to any external IP networks, which are not trusted. The LT-3110 Control Unit has Firewall rules configured on all Ethernet ports to avoid unwanted IP traffic.

DHCP client

The DHCP client mode is the configuration of the LT-3110 Control Unit from the factory. The DHCP client mode must be used, if the IP network already has a DHCP server available.

DHCP Server

The DHCP server mode must be used when connecting the LT-3110 Control Unit directly to another IP-device or local network, where no DHCP server is offered, and where it is required that a DHCP server is offered for assigning IP-addresses to network clients. The web server DHCP server mode setting is illustrated in Figure 144.




Figure 144: Web server – Network (DHCP server mode)

**NOTE:** A user scenario for configuration the DHCP server mode is when e.g. connecting IP-based communication devices: Analogue Phone Adapter, SIP Phones, or the RedPort Optimizer directly to the LT-3110 Control Unit via the Ethernet interface. Connecting an Analogue Phone Adapter is further described in *Analogue Phone Adapter* on page 63.



Static

The Static mode must be used when the IP-address of the LT-3100 Control Unit must never change. Typically used, if connecting the LT-3100 Control Unit to an IP-network, where a DHCP server is already available, and where it is important that the IP-address assigned for the LT-3100 Control Unit is never changed.




Figure 145: Web server – Network (Static mode)

**NOTE:** If the user changes DNS all clients’ needs to be rebooted as changes does not apply automatically

DNS

The LT-3100 system contains a caching recursive DNS server used to resolve names in the local domain. The system also contains two references to external DNS servers which are used to resolve names in the other domains. For configuration of the DNS servers see Figure 146.

**NOTE:** If the outgoing firewall is enabled the LT-3100 system will only allow domain names present in any firewall rules to be resolved externally. See Outgoing Firewall later in this section.




Figure 146: Web server – Network (DNS)

### DHCP

The DHCP tab shows the active DHCP leases. This includes LAN clients if ethernet is configured for DHCP server mode.




Figure 147: Web server – Network (DHCP)

Outgoing Firewall

Configuring the outgoing firewall allows the LT-3100 system operator to block all outgoing user network traffic apart from specified exceptions.

When adding rules to the outgoing firewall the user must for each rule provide a name for the rule and a destination domain name for which network traffic shall be allowed. e.g. predictwind.com, see Figure 148 below.




Figure 148: Web server – Network (Outgoing firewall)

**NOTE:** If the LT-3100 system is not setup in DHCP sever mode, LAN clients should have their DNS server address manually configured to the LAN IP address of the LT-3100.

If the user wants more configurability, then the Advanced options ticker can be clicked, allowing the user to configure, a name, a Destination domain or IP address, a chosen protocol, and which port to use. Protocol and Port selection can either be input or set to 'any'. See Figure 149 below for details.

LT-3100 System
UTC: 15 May 2023 13:30:21  
POSN: 55°49.153N 12°29.291E

Dashboard

Messages ∨

Configuration ∧

Authentication

Network

Bluetooth

Data

Telephony

Contacts

Tracking

External I/O

GNSS and BAM

Reset

Maintenance ∨

Legal notice

Log out

Disable login timeout

## Configuration - Network

Interfaces
DNS
DHCP
Outgoing Firewall
Static Route
PPPoE

The firewall service makes it possible to filter network data from the Bluetooth and PPPoE interfaces to the satellite network.

Enable

Advanced options

Block all user network traffic apart from the following exceptions

| Name                              | Destination domain or IP         | Protocol  | Port                             |  |
|-----------------------------------|----------------------------------|---|----------------------------------|--|
| Thrane                            | 192.168.1.1                      | TCP   | 80                               |  |
| PW                                | 155.88.126.10                    | UDP   | 66                               |  |
| <input type="text" value="Name"/> | <input type="text" value="Any"/> | <input type="text" value="Any"/> <span style="font-size: 0.8em;">▼</span> | <input type="text" value="Any"/> | <span style="font-size: 0.8em;">+</span> |

Note that when domain names are used as destination in firewall rules:

- Adding e.g. example.com will allow any IP protocol/port to that domain as well as any sub domains such as www.example.com, ftp.example.com etc.
- If the LT-3100 system is not setup in DHCP server mode, LAN clients must have their DNS server address manually configured to the LAN IP address of the LT-3100

Figure 149: Web server – Network (Outgoing firewall, advanced options)

### Static Route

It is possible to route IP data to other network segments on the LAN by using the Static Route feature of the LT-3100 system. This allows the user to configure rules containing the destination IP address and the used gateway.




Figure 150: Web server – Network (Static Route)

PPPoE

It is possible to setup the PPPoE service for the LT-3100 system, which makes it possible for a connected network device to create a point-to-point connection to the internet. As described in *PPPoE* on page 68 , the rules regarding outgoing firewall can be enabled for the PPPoE connection.

The PPPoE connection must be configured by setting up the Service name, Access Concentrator (AC) name, User name and Password. See Figure 151 for configuration.




Figure 151: Web server – Network (PPPoE)

## Bluetooth

The LT-3100 system has a Bluetooth transceiver built into the LT-3110 Control Unit. The LT-3100 system is currently only supporting the Bluetooth profile: Personal Area Network (PAN), the Headset profile is not supported. It is possible to enable the Bluetooth transceiver and change the device name in the web server, as illustrated in Figure 152.




Figure 152: Web server - Bluetooth

Bluetooth information is also available via the UI, which is described in *Settings, Bluetooth* on page 79.

**NOTE:** The built-in Bluetooth module and functionality will not be available in future production of the LT-3110 Control Unit due to manufacturer shortage and component obsolescence. In the display / GUI (MENU -> Settings -> Bluetooth) it can be verified if the Bluetooth module is mounted or not (the Bluetooth submenu will only be shown if the module is mounted).

## Data

The LT-3100 system is supporting Modem Data (Direct Internet, RUDICS and SBD) services via Serial over Ethernet on the Ethernet (RJ45) or Bluetooth interface. Serial over Ethernet is described in *Ethernet RJ45 (LAN)* on page 26. The Modem Data services are described in *Data (Modem Data, SMS and SBD)* on page 64.




Figure 153: Web server - Data

By activating 'Enable serial over network' the LT-3110 Control Unit will give access to the AT-command interface (port 5020) on the IP-address. The LT-3100 System is supporting Serial over Ethernet (RFC 2217), incl. all the hardware control signals, emulated over the Ethernet interface. It may be required to install a Virtual COM port (e.g., the Serial Port Redirector license) to have an external application work properly utilizing the Modem Data services.



**Telephony**

The LT-3100 System has a built-in PBX trunk (SIP), which supports internal and external satellite calling. The LT-3100 system only supports 1 x Iridium satellite voice channel. The PBX trunk (SIP) can be accessed via Ethernet, RJ45 or via the Bluetooth interface. Up to 8 external SIP devices can be registered in the PBX trunk. The web server, configuration - Telephony is illustrated in Figure 154.




Figure 154: Web server - Telephony

In the LT-3110 Control Unit, UI display (MENU -> System -> SIP Phones) it is possible to get an actual status of the number of SIP devices and their registration status. This is further illustrated and described in *System* on page 86.

The following external applications requires a SIP configuration:

- Connection of ships PBX
- External SIP Phones
- External Analogue Phone Adapter
- SIP Softphones via built-in Bluetooth module
- SIP Softphones via external Wi-Fi Access Point (WAP)

An incoming call to the LT-3100 system, will be signaled to all external SIP devices. The first SIP devices or LT-3120 Handset answering the incoming call will be connected. The LT-3100 system is currently not call forwarding.

**Contacts**

The user of the LT-3100 system can configure Contacts directly from the web server or from the LT-3110 Control Unit as described in *Phone* on page 75. It is possible to both edit and create new contacts. The web server contact list is identical to the one seen on the LT-3110 Control Unit.

To add a new contact, press the “+” sign, then input: Name, Phone Number and/or Email. When finished inputting information press the Apply button.




Figure 155: Web server - Telephony

**NOTE:** It is possible to edit contacts on the Web Server. To do so, edit Name, Phone number or Email address, and then press the Apply button.

Import / Export of contacts

The LT-31000 GMDSS system is supporting Import and Export of contact information via the web server. The system utilizes the Vcard format for both Import and Export of contacts. The system can Import and Export up to 100 contacts. See Figure 156 for details.




Figure 156: Web server (Contacts)

**Tracking**

The LT-3100 system supports tracking (position reporting) using different transport types and report formats. This section will briefly describe the different Tracking configurations options. For more details on Lars Thrane A/S tracking protocol supported in the LT-3100 system, please get in contact with Lars Thrane A/S. Figure 157 is illustrating the web server, tracking configuration.




Figure 157: Web server - Tracking

The tracking transport types, and report formats currently supported in the LT-3100 system are summarized in Table 29.

| Trigger Configurations |        |                |  |
|------------------------|--------|----------------|--|
| Trigger                | Format | Interval       | Comments   |
| <b>Time</b>            |        |                |  |
| Time interval          | HH:MM  | 0:01 to 168:00 | Time can be configured from 0.01 (1 minute) to 168:00 (up to 7 days)         |
| <b>Distance</b>        |        |                |  |
| Distance interval      | NM     | 0.1 to 999     | Distance can be configured from 0.1 to 999 NM                                |
| Minimum time interval  | HH:MM  | 0:01 to 168:00 | Minimum time can be configured from 0.01 (1 minute) to 168:00 (up to 7 days) |

Table 29: Web server – Tracking (transport types and report formats)

The time and distance trigger conditions can be configured individually. A tracking report will be sent, when a trigger condition has been met - time and/or distance. The trigger algorithm will 'reset' every time a tracking report has been sent.

The time trigger condition can be configured from 1 minute (0:01) and up to 7 days (168:00). The distance trigger condition can be configured from 0.1 NM and up to 999.0 NM. For the distance trigger condition, it is possible to configure a Minimum time interval, which has the purpose to make sure that not too many tracking reports are sent.

Example: If the distance interval is configured to 5.0 NM and Minimum time interval is configured to 01:00 hour, then position reports will be sent, when both requirements have been met (maximum every 1 hour). If the speed over ground is < than 5 knots, then a tracking report will be sent every 5.0 NM. If the speed over ground is > 5 knots, then a tracking report will be sent every 1 hour.

Under Options - Send report on power-on it is possible to configure the LT-3100 system to send a tracking report every time the terminal is powered on.

Use the button Send report now, illustrated in Figure 157 on page 121, to overwrite the tracking algorithm and send a tracking report instantly. Also, use the button to test the format of the tracking reports after tracking configurations have been applied.

**NOTE:** The LT-3110 Control Unit UI display has a tracking window (MENU -> System -> Tracking), providing tracking status overview. From this tracking window, it is possible to initiate a periodic tracking report (if configured) or initiate a tracking message, which will be sent to either an SMS or Email destination. For further details see *Tracking* on page 69.

**NOTE:** Lars Thrane A/S has an Interface Control Document (ICD) with details describing the following content: binary and text formats, remote management (configuration, requesting position report, and trigger position report). In order to support the Thrane (binary) format it is a requirement to get access to this ICD.

SBD

The LT-3100 system supports the Iridium SBD format, which is ideal, when sending many tracking reports. Using the SBD format requires an additional subscription, which can be activated via an Iridium Service Provider. In order for the Iridium Service Provider to activate the SBD service, the IMEI number of the radio module must be provided. The Iridium Service Provider will configure the SBD subscription and server, routing all SBD messages related to this IMEI number, to a specific address (e.g. Email address of the tracking server).

The IMEI number of the LT-3100 system can be found here:

- LT-3100 system box label
- LT-3130 Antenna Unit Test Sheet
- LT-3110 Control Unit, User Interface display (MENU -> System -> LT-3130 AU -> IMEI)




Figure 158: Web server – Tracking (SBD)

The following tracking portals are supporting the SBD (binary formats):

- Thrane (binary) -> TrakSat ([www.tracksat.net](http://www.tracksat.net)) IEC telecom
- SIRIUS track (binary) -> SIRIUStrack ([www.siriustrack.com](http://www.siriustrack.com)) Polaris Electronics A/S

**SMS**

The LT-3100 system supports SMS as transport type for tracking reports, see configuration options in Figure 159. The SMS tracking is supporting two formats: ‘Thrane (text)’ and ‘Human readable’. Be aware, that sending many tracking reports via SMS will not be the most affordable configuration.




Figure 159: Web server – Tracking (SMS)

The format of a tracking report (SMS - Human readable) sent to e.g. a smartphone is illustrated in Figure 160.




Figure 160: Tracking Report (SMS - Human Readable)

Email

The LT-3100 system supports Email as transport type for tracking reports, see configuration options in Figure 161. The Email tracking is supporting two formats: ‘Thrane (text)’ and ‘Human readable’.




Figure 161: Web server – Tracking (Email)

The format of a tracking report (Email – Thrane (text)) sent to an Email address is illustrated in Figure 162.




Figure 162: Tracking Report (Email – Thrane (text))



## Remote Management

The LT-3100 system supports Remote Management for the tracking application. In order for the Remote Management to work, the Remote Management must be enabled by the user and a password must be chosen as illustrated on Figure 163. The Remote Management is using the SMS service as communication layer.




Figure 163: Web server (Tracking - Remote Management)

The Tracking Remote Management functionality is supporting:

- Request Position Report
- Trigger Position Report
- Change Tracking Configuration

**NOTE:** It is always possible to reset or change the Remote Management password over-the-air, even when the password has been lost or has never been enabled. This function requires application software LT-3100-v1.15R or newer. For further information and assistance, contact Lars Thrane A/S.

**NOTE:** For further details about the Remote Management functionality, please contact Lars Thrane A/S.

**External – I/O**

The LT-3100 system support configuration of External I/O. The LT-3100 system has one input and one output supported in the AUX connector. The AUX connector is described in *Auxiliary (AUX)* on page 27. Figure 164 is illustrating the configuration of the External I/O.




Figure 164: Web server – External I/O

Output

| External I/O – Output Configuration |                |
|-------------------------------------|----------------|
| Not assigned                        |                |
| External Ringer                     | Level          |
|                                     | Pulse @ 0.5 Hz |
|                                     | Pulse @ 1 Hz   |
|                                     | Pulse @ 2 Hz   |

Table 30: External I/O - Output

The External I/O output configuration options are listed in Table 30.

Input

The LT-3100 system is currently not supporting the External I/O input.

**GNSS and BAM**

The LT-3100 system has a built-in GNSS receiver located in the LT-3130 Antenna Unit. The GNSS receiver is used for time, date and position of the LT-3100 system, for example by the tracking application. The GNSS receiver can be configured to operate on different satellite systems (e.g. GPS only) - this can be managed under the GNSS module, as illustrated in Figure 165.

It is possible to configure the following functionality: GNSS and BAM on the LT-3110 Control Unit (CU - AUX) interface.

This section describes the following configuration options:

- GNSS module
- GNSS (output of NMEA 0183 sentences)
- Bridge Alert Management (BAM)




Figure 165: Web server – GNSS and NMEA output

**NOTE:** The Port configuration illustrated above in Figure 165 for GNSS and BAM supports the following baud rates: 4800, 9600, and 38400. The port is bi-directional RS-422. Only BAM can receive data.

GNSS module

The GNSS receiver used in the LT-3130 Antenna Unit is a 72 ch. receiver with SBAS reception. The GNSS receiver performance is listed in Table 31.

| GNSS receiver performance |                              |            |   |
|---------------------------|------------------------------|------------|---|
| Data                      | Accuracy                     | Resolution | Comments  |
| Position                  | GNSS: < 2.5 m<br>SBAS: < 2 m | 0.1 m      | CEP, 50%, 24 hours static, -130 dBm, > 6 SVs<br>By default, the GNSS receiver is configured for GPS, SBAS, GLONASS reception<br>Time-To-First-Fix (cold acquisition): 26 s. |
| SOG                       | 0.1 knot                     | 0.1 knot   | 0 to 195 knots  |

Table 31: GNSS receiver performance

The GNSS receiver can be configured to the options listed in Table 32. The GPS, SBAS, GLONASS configuration is the default configuration.

| GNSS Receiver configuration |           |
|-----------------------------|-----------|
| GNSS Receiver               | Talker ID |
| GPS, SBAS, GLONASS          | GN        |
| GPS, SBAS, BeiDou           | GN        |
| GPS, SBAS                   | GP        |
| GPS                         | GP        |
| GLONASS                     | GL        |
| BeiDou                      | GB        |

Table 32: GNSS receiver configuration

The horizontal position accuracy (static) has been measured for different configurations of the GNSS receiver, see Figure 166.




Figure 166: GNSS receiver horizontal position error

**IMPORTANT:** The installation of the LT-3130 Antenna Unit will affect the performance of the GNSS receiver. If line-of-sight to the GNSS satellites are disturbing the quality of the signal received by the GNSS receiver, then degraded performance must be accepted.

GNSS

The LT-3100 system supports outputting of GNSS NMEA 0183 sentences via the LT-3110 Control Unit AUX (RS-422). The AUX connector is described in detail in *Auxiliary (AUX)* on page 27. The GNSS output must be enabled via the web server, under Configuration – GNSS and BAM. The baud rate can be configured to 4.800, 9.600, or 38.400 baud. The output rate of the NMEA 0183 sentences is 1 Hz. Figure 167 below shows the NMEA 0183 sentences supported by the LT-3100 system.




Figure 167: Web server (GNSS - NMEA 0183 sentences)

The GSV sentence is not supported for the 4.800 and 9.600 baud configuration.

**NOTE:** Changing the GNSS receiver configuration (default: GPS, SBAS, GLONASS) might affect the NMEA 0183 Talker ID. The Talker ID for the different configurations of the GNSS receiver is listed in Table 32 on page 129.

**BAM**

The LT-3100 system supports BAM via the LT-3110 Control Unit AUX (RS-422) The AUX connector is described in detail in *Auxiliary (AUX)* on page 27. BAM must be enabled via the web server, under Configuration – GNSS and BAM. The baud rate can be configured to 4.800, 9.600, or 38.400 baud. For BAM configuration see Figure 168 below.




Figure 168: Web server (BAM configuration)

**NOTE:** The LT-3110 Control Unit AUX connector is providing one bi-directional RS-422 interface.

The Supported BAM sentences are described in *BAM sentences* on page 96.

**Reset to factory default**

The LT-3100 system supports reset to factory default. This reset functionality is only available via the web server, see Figure 169. By pressing ‘Reset to factory default’ and acknowledging this reset, the LT-3100 system will configure all settings to default and remove all user data (e.g., Contact List, Call History, SMS, etc.). The LT-3100 system will reboot once the factory reset has been affected.

It is also possible to just reset the network configuration to the default settings. This enables the user to clear any network configuration rules without resetting the entire system, which will reset the LT-3100 system to its default state




Figure 169: Web server (Reset to Factory Default)

**NOTE:** Using ‘Reset to factory default’ the LT-3100 system will lose all settings configured and user data will be lost. The system will be operational again once it has rebooted

The default values for display and audio settings are displayed in Table 33 below.

| Default Display and Audio settings |          |
|------------------------------------|----------|
| Display, Mode                      | Day time |
| Display, Brightness                | 70%      |
| Speaker volume                     | 80%      |
| Handset volume                     | 60%      |
| Ringer volume                      | 80%      |
| Key Beep volume                    | 40%      |

Table 33: Default display and audio settings

## Maintenance

### Diagnostics

A diagnostic report can be downloaded from the webpage 'Diagnostics'. Navigate to the webpage and press the 'Download diagnostics report' button. A file with the following filename (example): LT-3100\_00000061\_191115-152149.tar.gz will be downloaded to a location selected by the user. The Diagnostics Report can be sent back to Lars Thrane A/S in case of required support and assistance. The Diagnostics Report contains data describing the current state of the system and historical events. The data can be used by support to identify issues and determine their cause.

To help identifying a potential problem with the LT-3100 system it is very important that the Diagnostic Report is sent back to Lars Thrane A/S.




Figure 170: Web server (download diagnostics report)

**NOTE:** The diagnostic report is encrypted and can only be read by Lars Thrane A/S. Lars Thrane A/S does not share the data in the diagnostics report with any third party. By downloading and sending the diagnostic report to Lars Thrane A/S you attest to having read, understood, and agreed to the conditions stated under the *Notice!* (highlighted in Figure 170 above)



## Software update

Carefully read the software release note, provided by Lars Thrane A/S, before software updating the LT-3100 system.

Access the web server of the LT-3100 system, by following the instructions in *Accessing the built-in web server* on page 99. Select the 'Software update' web page and click the 'Choose File' button to select the LT-3100 system file, which must be uploaded to the system. The software image has the following filename (example): LT-3100-v1.15R-0003.lti - the software image and release documentation will be available on the official company website: <https://www.thrane.eu>, under the specific product or in the Partner Area. Click the 'Upload' button to start the upload of the new software image. The upload and installation of the software image will take a few minutes. Progress indication bars can be monitored on the Software update webpage, while the software update is on-going. The LT-3100 system will reboot once the software image is installed safely in all units.




Figure 171: Web server (Software update)

**NOTE:** The LT-3110 Control Unit and LT-3130 Antenna Unit, must be operated with the same software version. The software update will happen automatically, if the control unit identifies that the software version in the antenna is different. Check or verify the web server Dashboard for software versions in each of the LT-3100 system units, see *Dashboard* on page 100.

**IMPORTANT:** Do not remove power from the control unit while the software update is on-going. Also, do not disconnect the antenna cable between the control unit and the antenna unit, while the software update is on-going.

**IMPORTANT:** The Advanced Settings shall not be used under normal circumstances. Do not use this function unless specifically instructed by Lars Thrane A/S or by the Lars Thrane A/S certified partner.

**Legal notice**

The LT-3100 system contains Open Source software components. The Open Source software components used and related license information can be viewed by pressing the link ‘here’ under the Legal notice webpage, see Figure 172.



Figure 172: Web server (legal notice)

**Log out**

By pressing the ‘Log out’ webpage the web server will redirect you to the Authentication login, where it is required to use the Username and Password to re-enter the web server again. The Authentication is described in *Authentication* on page 104.

**Disable login timeout**

The web server will automatically logout after 5 minutes without activity. The user can disable this automatic logout by pressing the ‘Disable login timeout’ webpage, which then will change to a red color and text: ‘Enable login timeout’. The user must manually remove this configuration by pressing the webpage to go back to default settings and automatically logout.




Figure 173: Web server (disable login timeout)

## Service & Repair

This section describes what the end-user must do in case of required service or repair.

**NOTE:** The LT-3100 system does not require any scheduled maintenance or service. Make sure that the product is installed, as described in this manual, before making contact to the distributor or dealer for further assistance.

If the LT-3100 system for some reason does not work as described in this manual, contact the distributor or dealer, from where the product was originally bought. The distributor or dealer will have experience and know-how to assist with further technical support and troubleshooting.

### Contacting the distributor/dealer:

- 1) Make sure to have the product name, unit part numbers, and unit serial numbers identified. The unit part numbers, and the unit serial numbers are identified on the unit label, which is found on the backside, or at the bottom side of the units. Alternatively, use the built-in web server to read-out the unit part numbers and the unit serial numbers.
- 2) Write a technical report about the observation or error. If possible, attach a picture of the installed product and include a wiring diagram. If possible, download a diagnostic report as described in *Diagnostic* on page 133.
- 3) Send all information to the local distributor or dealer.

**IMPORTANT:** Unless otherwise agreed, the end-user shall always coordinate service and repair issues directly with the distributor or dealer. This practice also applies for returning of products for service and repair.

All information that will get back to Lars Thrane A/S, either directly or indirectly, will be handled with confidentiality. End-user sensitive data will not be shared with any third party without prior written acceptance from the involved parties.

## Appendixes

### App. A - Applicable Standards

- [1] IEC 62923-1  
Maritime navigation and radiocommunication equipment and systems - Bridge alert management  
Part 1: Operational and performance requirements, methods of testing and required test results
- [2] IEC 62923-2  
Maritime navigation and radiocommunication equipment and systems - Bridge alert management  
Part 2: Alert and cluster identifiers and other additional features

**App. B - Bridge Alert Management (BAM)**

Alert generating functions

| Name          | Can be deactivated | Description   |
|---------------|--------------------|---|
| GNSS Position | No                 | The system can be only configured to use either GNSS position (automatic).  |
| SIM           | No                 | Responsible for managing the Subscriber Identity Module (SIM) card. It is not possible to deactivate this function. |

*Table 34: Alert generating functions*

The LT-3100 system contains the following functions capable of raising

Alert categories

The BAM concept groups alerts into categories as a mean to indicate where an alert may be acknowledged (and thus also whether it can have its responsibility transferred):

| Category | Description   |
|----------|---|
| A        | Alert for which additional information at the alert source is necessary, as decision support for the evaluation of the alert related condition.<br>Alert can only be acknowledged at the alert source.        |
| B        | Alert where no additional information for decision support is necessary besides the information which can be presented at the CAM UI.<br>Alert may be acknowledged at the alert source and/or the CAM system. |
| C        | Alert that cannot be acknowledged on the bridge but for which information is required about the status and treatment of the alert.  |

*Table 35: BAM alert categories*

List of alerts

|                     |  |                  |         |                  |     |                        |     |
|---------------------|--|------------------|---------|------------------|-----|------------------------|-----|
| <b>ID:</b>          | 3022   | <b>Priority:</b> | Warning | <b>Category:</b> | B   | <b>Resp. transfer:</b> | Yes |
| <b>Title:</b>       | Power fail   |                  |         | <b>Can ACK:</b>  | Yes | <b>Transitory:</b>     | No  |
| <b>Description:</b> | CU input voltage too high. Check power supply  |                  |         |                  |     |                        |     |
| <b>What to do:</b>  | Check the output voltage of the power supply   |                  |         |                  |     |                        |     |
| <b>Conditions:</b>  | Raised when the Control Unit detects a too high input voltage.<br>Rectified when the input voltage is normalized |                  |         |                  |     |                        |     |
| <b>Escalation:</b>  | Repeated as a warning after 90 s.  |                  |         |                  |     |                        |     |

|                     |   |                  |         |                  |     |                        |     |
|---------------------|---|------------------|---------|------------------|-----|------------------------|-----|
| <b>ID:</b>          | 3022  | <b>Priority:</b> | Warning | <b>Category:</b> | B   | <b>Resp. transfer:</b> | Yes |
| <b>Title:</b>       | Power fail  |                  |         | <b>Can ACK:</b>  | Yes | <b>Transitory:</b>     | No  |
| <b>Description:</b> | CU input voltage too low. Check power supply  |                  |         |                  |     |                        |     |
| <b>What to do:</b>  | Check the output voltage of the power supply  |                  |         |                  |     |                        |     |
| <b>Conditions:</b>  | Raised when the Control Unit detects a too low input voltage.<br>Rectified when the input voltage is normalized |                  |         |                  |     |                        |     |
| <b>Escalation:</b>  | Repeated as a warning after 90 s.   |                  |         |                  |     |                        |     |

|                     |   |                  |         |                  |     |                        |     |
|---------------------|---|------------------|---------|------------------|-----|------------------------|-----|
| <b>ID:</b>          | 3022  | <b>Priority:</b> | Warning | <b>Category:</b> | B   | <b>Resp. transfer:</b> | Yes |
| <b>Title:</b>       | Power fail  |                  |         | <b>Can ACK:</b>  | Yes | <b>Transitory:</b>     | No  |
| <b>Description:</b> | AU input voltage too low. Refer to user manual  |                  |         |                  |     |                        |     |
| <b>What to do:</b>  | Check the DC resistance of the coaxial cable is below the maximum allowed as specified in <i>LT-3130 Antenna Unit</i> on page 32. |                  |         |                  |     |                        |     |
| <b>Conditions:</b>  | Raised when the Antenna Unit detects a too low input voltage.<br>Rectified when the input voltage is normalized                   |                  |         |                  |     |                        |     |
| <b>Escalation:</b>  | Repeated as a warning after 90 s.   |                  |         |                  |     |                        |     |

|                     |  |                  |         |                  |     |                        |     |
|---------------------|--|------------------|---------|------------------|-----|------------------------|-----|
| <b>ID:</b>          | 3062   | <b>Priority:</b> | Warning | <b>Category:</b> | B   | <b>Resp. transfer:</b> | Yes |
| <b>Title:</b>       | System fault   |                  |         | <b>Can ACK:</b>  | Yes | <b>Transitory:</b>     | No  |
| <b>Description:</b> | System self-check error. Try power-cycle system                              |                  |         |                  |     |                        |     |
| <b>What to do:</b>  | Power-cycle the system. If that does not help, contact the service provider. |                  |         |                  |     |                        |     |
| <b>Conditions:</b>  | Raised when the system self-check detects an unspecified internal error.     |                  |         |                  |     |                        |     |
| <b>Escalation:</b>  | Repeated as a warning after 90 s.  |                  |         |                  |     |                        |     |

|                     |  |                  |         |                  |   |  |  |
|---------------------|--|------------------|---------|------------------|---|--|--|
| <b>ID:</b>          | 3116   | <b>Priority:</b> | Caution | <b>Category:</b> | B |  |  |
| <b>Title:</b>       | Lost connection  |                  |         |                  |   |  |  |
| <b>Description:</b> | Check satellite terminal   |                  |         |                  |   |  |  |
| <b>What to do:</b>  | Verify the Antenna Unit has free line of sight to the sky. Remove any object blocking the line of sight if possible.   |                  |         |                  |   |  |  |
| <b>Conditions:</b>  | Raised when the terminal has been unable to detect or otherwise contact the satellites of the Iridium® satellite system for a period of one minute or more. Rectified when the terminal detects the Iridium® satellite system. |                  |         |                  |   |  |  |

|                     |  |                  |         |                  |     |                        |     |
|---------------------|--|------------------|---------|------------------|-----|------------------------|-----|
| <b>ID:</b>          | 11412  | <b>Priority:</b> | Warning | <b>Category:</b> | B   | <b>Resp. transfer:</b> | Yes |
| <b>Title:</b>       | Lost Handset   |                  |         | <b>Can ACK:</b>  | Yes | <b>Transitory:</b>     | No  |
| <b>Description:</b> | Voice calls unavailable. Check handset cable   |                  |         |                  |     |                        |     |
| <b>What to do:</b>  | Check the cable between the handset and the Control Unit   |                  |         |                  |     |                        |     |
| <b>Conditions:</b>  | Raised when Control Unit loose connection with the Handset<br>Rectified when connection is reestablished with the Handset. |                  |         |                  |     |                        |     |
| <b>Escalation:</b>  | Repeated as a warning after 90 s.  |                  |         |                  |     |                        |     |

|                     |  |                  |         |                  |     |                        |     |
|---------------------|--|------------------|---------|------------------|-----|------------------------|-----|
| <b>ID:</b>          | 11412  | <b>Priority:</b> | Warning | <b>Category:</b> | B   | <b>Resp. transfer:</b> | Yes |
| <b>Title:</b>       | Lost antenna   |                  |         | <b>Can ACK:</b>  | Yes | <b>Transitory:</b>     | No  |
| <b>Description:</b> | Iridium service unavailable. Check antenna cable   |                  |         |                  |     |                        |     |
| <b>What to do:</b>  | Check the cable between the Control Unit and the Antenna Unit.   |                  |         |                  |     |                        |     |
| <b>Conditions:</b>  | Raised when Control Unit loose connection with the Antenna Unit<br>Rectified when connection is reestablished with the Antenna Unit. |                  |         |                  |     |                        |     |
| <b>Escalation:</b>  | Repeated as a warning after 90 s.  |                  |         |                  |     |                        |     |

|                     |  |                  |         |                  |     |                        |     |
|---------------------|--|------------------|---------|------------------|-----|------------------------|-----|
| <b>ID:</b>          | 11422  | <b>Priority:</b> | Warning | <b>Category:</b> | B   | <b>Resp. transfer:</b> | Yes |
| <b>Title:</b>       | Software fault   |                  |         | <b>Can ACK:</b>  | Yes | <b>Transitory:</b>     | No  |
| <b>Description:</b> | Software does not support hardware   |                  |         |                  |     |                        |     |
| <b>What to do:</b>  | Install the latest software.   |                  |         |                  |     |                        |     |
| <b>Conditions:</b>  | Raised when the software detects hardware that is not supported by the software. |                  |         |                  |     |                        |     |
| <b>Escalation:</b>  | Repeated as a warning after 90 s.  |                  |         |                  |     |                        |     |

|                     |  |                  |         |                  |     |                        |     |
|---------------------|--|------------------|---------|------------------|-----|------------------------|-----|
| <b>ID:</b>          | 11422  | <b>Priority:</b> | Warning | <b>Category:</b> | B   | <b>Resp. transfer:</b> | Yes |
| <b>Title:</b>       | Software fault                                       |                  |         | <b>Can ACK:</b>  | Yes | <b>Transitory:</b>     | No  |
| <b>Description:</b> | Please reinstall software                            |                  |         |                  |     |                        |     |
| <b>What to do:</b>  | Install the latest software.                         |                  |         |                  |     |                        |     |
| <b>Conditions:</b>  | Raised when a software updated completed in failure. |                  |         |                  |     |                        |     |
| <b>Escalation:</b>  | Repeated as a warning after 90 s.                    |                  |         |                  |     |                        |     |



|                     |  |                  |                 |                  |                    |                        |     |
|---------------------|--|------------------|-----------------|------------------|--------------------|------------------------|-----|
| <b>ID:</b>          | 15102  | <b>Priority:</b> | Warning         | <b>Category:</b> | B                  | <b>Resp. transfer:</b> | Yes |
| <b>Title:</b>       | Lost SIM card  |                  | <b>Can ACK:</b> | Yes              | <b>Transitory:</b> | No                     |     |
| <b>Description:</b> | Check SIM card   |                  |                 |                  |                    |                        |     |
| <b>What to do:</b>  | Verify the SIM card is properly inserted (see <i>SIM card (SIM)</i> on page 25).                       |                  |                 |                  |                    |                        |     |
| <b>Conditions:</b>  | Raised when the SIM card is removed or cannot be detected.<br>Rectified when the SIM card is detected. |                  |                 |                  |                    |                        |     |
| <b>Escalation:</b>  | Repeated as a warning after 90 s.  |                  |                 |                  |                    |                        |     |

|                     |  |                  |                 |                  |                    |                        |     |
|---------------------|--|------------------|-----------------|------------------|--------------------|------------------------|-----|
| <b>ID:</b>          | 15502  | <b>Priority:</b> | Warning         | <b>Category:</b> | B                  | <b>Resp. transfer:</b> | Yes |
| <b>Title:</b>       | Connection fail  |                  | <b>Can ACK:</b> | Yes              | <b>Transitory:</b> | No                     |     |
| <b>Description:</b> | Rejected by the Iridium network. Contact service provider          |                  |                 |                  |                    |                        |     |
| <b>What to do:</b>  | Contact the service provider and check the subscription is valid.  |                  |                 |                  |                    |                        |     |
| <b>Conditions:</b>  | Raised when the terminal fails to register on the Iridium network. |                  |                 |                  |                    |                        |     |
| <b>Escalation:</b>  | Repeated as a warning after 90 s.                                  |                  |                 |                  |                    |                        |     |

**App. C - Multiple talkers and multiple listeners**

IEC 61162 *Multiple talkers and multiple listeners* is a series of protocol definitions supporting both RS-422 and Ethernet for transporting its messages.

LT-3100 system currently supports IEC 61162 over RS-422 only but is prepared for future support of IEC 61162 over Ethernet. Certification of compliance with IEC 61162-450 and IEC 61162-460 has been obtained and thus the LT-3100 system is permitted to be connected to an IEC 61162 Ethernet network, though none of their functions are supported.

**ONF network node**

The LT-3100 system is classified as an ONF network node by IEC 61162 using the following protocols: DHCP, IPv4, IPv4LL, UDP, TCP, SIP, RTP, HTTP, HTTPS.

**App. D - GNSS sentences**

This appendix provides detailed information about the GNSS sentences supported by the LT-3100 system. For further details see *GNSS sentences* on page 95 and web server configuration *GNSS and BAM* on page 128.

GNSS Talker identification mnemonics

The LT-3100 system may use the following talker identifiers:

| GNSS Talker Identification Mnemonics      |            |          |
|---|------------|----------|
| Talker Device                             | Identifier | Function |
| Global Navigation Satellite System (GNSS) | GN         | GNSS     |
| Global Positioning System (GPS)           | GP         | GNSS     |
| GLONASS positioning system                | GL         | GNSS     |
| BeiDou positioning system                 | GB         | GNSS     |

*Table 36: GNSS Talker identification mnemonics*

GNSS Talker Sentence Overview

| GNSS Talker Sentences |          |  |                       |
|-----------------------|----------|--|-----------------------|
| Sentence Formatter    | Function | Description                                | Transmission Interval |
| DTM                   | GNSS     | Datum reference                            | 1 s                   |
| GGA                   | GNSS     | Global positioning system (GPS) fix data   | 1 s                   |
| GLL                   | GNSS     | Geographic position – latitude / longitude | 1 s                   |
| GSA                   | GNSS     | GNSS DOP and active satellites             | 1 s                   |
| GSV                   | GNSS     | GNSS satellites in view                    | 1 s                   |
| RMC                   | GNSS     | Recommended minimum specific GNSS data     | 1 s                   |
| VTG                   | GNSS     | Course over ground and ground speed        | 1 s                   |
| ZDA                   | GNSS     | Time and date                              | 1 s                   |

*Table 37: GNSS Talker Sentences*

The table below lists all GNSS sentences the LT-3100 system can transmit (as a talker):

GNSS Listener sentences overview

No listener sentences available for GNSS.

**App. E - BAM Sentences**

This appendix provides detailed information about the BAM sentences supported by the LT-3100 system. For further details see *BAM sentences* on page 96 and web server configuration *GNSS and BAM* on page 128.

BAM Talker identification mnemonics

The LT-3100 system may use the following talker identifiers:

| BAM Talker Identification Mnemonics |            |          |
|-------------------------------------|------------|----------|
| Talker Device                       | Identifier | Function |
| Communications - satellite          | CS         | BAM      |

*Table 38: BAM talker identification mnemonics*

BAM Talker Sentence Overview

| BAM Talker Sentences |          |                       |                       |
|----------------------|----------|-----------------------|-----------------------|
| Sentence Formatter   | Function | Description           | Transmission Interval |
| ALC                  | BAM      | Cyclic alert list     | 30 s                  |
| ALF                  | BAM      | Alert sentence        | n/a                   |
| ARC                  | BAM      | Alert command refused | n/a                   |

*Table 39: BAM talker sentences*

The table below lists all BAM sentences the LT-3100 system can transmit (as a talker):

BAM Listener sentences overview

| BAM Listener Sentences |          |                                 |          |
|------------------------|----------|---------------------------------|----------|
| Sentence Formatter     | Function | Description                     | Presence |
| ACN                    | BAM      | Alert command                   | Optional |
| HBT                    | BAM      | Heartbeat supervision sentences | Optional |

*Table 40: BAM listener sentences*

The table below lists all sentences the LT-3100 system can receive (as a listener):

**App. F - GNSS Receiver Integrity States**

The LT-3100 system has a built-in GNSS receiver located in the LT-3130 Antenna Unit. The GNSS receiver is used under normal conditions for providing the LT-3100 system with time, data, and position information to all required functions in the system. Position Status is located in the System submenu (MENU -> System) described and illustrated in *System* starting on page 86. Table 41 illustrates the GNSS receiver integrity states. The color marking has the following meaning:

- Colored Yellow -> low integrity
- Colored Orange-> Invalid

| GNSS Receiver Integrity States (Automatic GNSS)                        |              |                          |                   |                     |         |           |  |
|--|--------------|--------------------------|-------------------|---------------------|---------|-----------|--|
| State  | UTC          | POSN                     | POSN (age)        | Horizontal Accuracy | COG [°] | SOG [kts] | Comments                                     |
| System has just booted and there is not yet a fix                      | Acquiring... | Acquiring...             | -                 | -                   | -       | -         | System booting up                            |
| System has just booted and only time is known                          | Time         | Acquiring...             | -                 | -                   | -       | -         | System booting up                            |
| Horizontal accuracy > 50 m (SOG = 0 kts)                               | Time         | Lat/Long                 | Up to date        | > 50 m              | XXX.X   | XX.X      | System booting up                            |
| Horizontal accuracy < 50 m (SOG = 0 kts)                               | Time         | Lat/Long                 | Up to date        | < 50 m              | XXX.X   | XX.X      | Normal GNSS receiver state.                  |
| SOG > 1 m/s (~ 2 kts)  | Time         | Lat/Long                 | Up to date        | < 50 m              | XXX.X   | XX.X      | Normal GNSS receiver state.                  |
| GNSS fix completely lost (last known position has age > 0 min)         | Time (old)   | Lat/Long                 | > 0 min           | -                   | -       | -         | No fix on GNSS receiver (time and position). |
| GNSS fix completely lost (last known position has age 23 hours 59 min) | Time (old)   | Lat/Long                 | ≤ 23 hours 59 min | -                   | -       | -         | No fix on GNSS receiver (time and position). |
| GNSS fix completely lost (last known position has age ≥ 24 hours)      | Time (old)   | Lat/Long<br>Acquiring... | ≥ 24 hours        | -                   | -       | -         | No fix on GNSS receiver (time and position). |

Table 41: GNSS Receiver Integrity States (Automatic GNSS)

Table 41 is illustrating the GNSS receiver integrity states .The following pages will illustrate all relevant states.

System has just booted and there is not yet a fix




Figure 174: GNSS Receiver Integrity State




Figure 175: GNSS Receiver Integrity State

System has just booted and only time is known




Figure 176: GNSS Receiver Integrity State




Figure 177: GNSS Receiver Integrity State

Horizontal accuracy > 50 m (SOG = 0 kts)




Figure 178: GNSS Receiver Integrity State




Figure 179: GNSS Receiver Integrity State

Horizontal accuracy < 50 m (SOG = 0 kts)




Figure 180: GNSS Receiver Integrity State




Figure 181: GNSS Receiver Integrity State

SOG > 1 m/s (~ 2 kts)

UTC: 2020-11-24 19:56  
 POSN: 55°49.152N 012°29.290E

| Position Status  |                  |
|------------------|------------------|
| Fix Type         | 3D + DGNSS       |
| Latitude         | 55°49.152N       |
| Longitude        | 012°29.290E      |
| Time of Position | 2020-11-24 19:56 |
| COG              | 153.6°           |

Figure 182: GNSS Receiver Integrity State

UTC: 2020-11-24 19:56  
 POSN: 55°49.152N 012°29.290E

| Position Status   |                  |
|-------------------|------------------|
| Time of Position  | 2020-11-24 19:56 |
| COG               | 153.6°           |
| SOG               | 2.0 knots        |
| Accuracy          | < 0.8 m          |
| Satellites In Use | 20               |

Figure 183: GNSS Receiver Integrity State

GNSS fix completely lost (last known position has age 10 min)

GNSS Position (-00:10) !  
 POSN: 55°49.151N 012°29.290E

| Position Status  |                  |
|------------------|------------------|
| Fix Type         | -                |
| Latitude         | 55°49.151N       |
| Longitude        | 012°29.290E      |
| Time of Position | 2020-11-24 20:00 |
| COG              | -                |

Figure 184: GNSS Receiver Integrity State

GNSS Position (-00:10) !  
 POSN: 55°49.151N 012°29.290E

| Position Status   |                  |
|-------------------|------------------|
| Time of Position  | 2020-11-24 20:00 |
| COG               | -                |
| SOG               | -                |
| Accuracy          | -                |
| Satellites In Use | -                |

Figure 185: GNSS Receiver Integrity State



GNSS fix completely lost (last known position has age 23 hours 59 min)




Figure 186: GNSS Receiver Integrity State




Figure 187: GNSS Receiver Integrity State

GNSS fix completely lost (last known position has age >= 24 hours)




Figure 188: GNSS Receiver Integrity State




Figure 189: GNSS Receiver Integrity State

**App. G - Specifications****LT-3100 Satellite Communications System**

|  |   |
|--|---|
| Certification & standards              | Maritime CE, RED, ISED, FCC, RCM, RoHS, Iridium®          |
| Vibration, operational                 | IEC 60945 (sine) & proprietary<br>Maritime Random profile |
| Vibration, survival                    | Proprietary Maritime Random profile                       |
| Vibration, shock                       | Proprietary Maritime profile (20 g, 11 ms)                |
| Power consumption: operating mode, max | 40.8 W  |
| Power consumption: Idle                | 9 W   |

**LT-3110 Control Unit**

|                                     |  |
|-------------------------------------|--|
| Weight                              | 658 g (1.45 lbs)   |
| Dimensions                          | 224.0 x 120.0 x 70.0 mm (8.82 x 4.72 x 2.76 in)  |
| Temperature, operational            | -15°C to +55°C (+5°F to +131°F)  |
| IP rating, dust and water           | IP 32  |
| Interfaces                          | Ethernet, auxiliary, DC input, chassis ground<br>Antenna Unit (N conn.), handset, Bluetooth,<br>SIM card |
| Input voltage                       | 12 - 24 VDC (2.2-1.7A)   |
| BT transmitter, Max RF output power | 10mW   |
| BT transmitter, Frequency bands     | TX: 2402-2480MHz, RX:2402-2480MHz  |
| Compass Safe Distance, std.         | 0.60 m (2.0 ft)  |
| Compass Safe Distance, steer.       | 0.40 m (1.3 ft)  |

**LT-3120 Handset**

|                               |  |
|-------------------------------|--|
| Weight                        | 290 g (0.64 lbs)                               |
| Dimensions                    | 208.8 x 52.8 x 38.2 mm (8.22 x 2.08 x 1.50 in) |
| Temperature, operational      | -15°C to +55°C (+5°F to +131°F)                |
| IP rating, dust and water     | IP32   |
| Compass Safe Distance, std.   | 0.60 m (2.0 ft)                                |
| Compass Safe Distance, steer. | 0.35 m (1.1 ft)                                |

**LT-3121 Cradle**

|                               |  |
|-------------------------------|--|
| Weight                        | 66 g (0.15 lbs)                                |
| Dimensions                    | 106.9 x 57.4 x 29.3 mm (4.21 x 2.26 x 1.15 in) |
| Compass Safe Distance, std.   | 1.40 m (4.6 ft)                                |
| Compass Safe Distance, steer. | 0.90 m (3.0 ft)                                |

**LT-3130 Antenna Unit (HVIN = 2)**

|   |   |
|---|---|
| Weight  | 687 g (1.51 lbs)  |
| Dimensions                                    | 151.1 x Ø 149.5 mm (5.95 x Ø 5.89 in)                         |
| Temperature, operational (12 VDC input power) | -30°C to +55°C (-30°F to +131°F)                              |
| Temperature, operational (24 VDC input power) | -40°C to +55°C (-40°F to +131°F)                              |
| IP rating, dust and water                     | IP67  |
| Interfaces                                    | Control Unit (N conn.)<br>Coaxial cable, up to 500m (1500 ft) |
| Antenna communication cable                   |   |
| Compass Safe Distance, std.                   | 0.30 m (1.0 ft)   |
| Compass Safe Distance, steer.                 | 0.30 m (1.0 ft)   |

|             |         |
|-------------|---------|
| Warranty    | 2 years |
| Maintenance | None    |

App. H - Outline Drawing: LT-3110 Control Unit





Figure 190: Outline Drawing: LT-3110 Control Unit

**App. I - Outline Drawing: Bracket Mount, Control Unit**



*Figure 191: Outline Drawing: Bracket Mount, Control Unit*

App. J - Outline Drawing: Flush Mount, Control Unit





Figure 192: Outline Drawing: Flush Mount, Control Unit

**App. K - Outline Drawing: LT-3130 Antenna Unit**



*Figure 193: Outline Drawing: LT-3130 Antenna Unit*

**App. L - Outline Drawing: Pole Mount (1.5" pipe, 38.8mm), Antenna Unit**

**NOTE:** The Pole Mount (1.5" pipe), Antenna Unit interfaces to a pipe of maximum 1.5" (38.1 mm), measured outer diameter. The total weight of the Pole Mount is 190 g (0.42 lbs).




Figure 194: Outline Drawing: Pole Mount (1.5" pipe), Antenna Unit

**App. M - Outline Drawing: Pole Mount (2.0" pipe, 53.0 mm), Antenna Unit**

**NOTE:** The Pole Mount (2.0" pipe, 53.0 mm), Antenna Unit interfaces to a pipe of maximum 2.0" (53.0 mm), measured outer diameter. The total weight of the Pole Mount is 0.24 kg (0.53 lbs).




Figure 195: Outline Drawing: Pole Mount (2.0" pipe,  $\phi 53.0$  mm), Antenna Unit



App. N - Outline Drawing: LT-3120 Handset




Figure 196: Outline Drawing: LT-3120 Handset

App. O - Outline Drawing: LT-3121 Cradle




Figure 197: Outline Drawing: LT-3121 Cradle

**App. P - EU Declaration of Conformity**

68-101340 Rev. 1.02



**EU Declaration of Conformity**

This declaration of conformity is issued under the sole responsibility of the manufacturer.

**Manufacturer:** Lars Thrane A/S  
**Address:** Skovlytoften 33, 2840 Holte, Denmark

**Product Identification:**  
 LT-3100 Satellite Communications System  
 51-100987 LT-3110 Control Unit      51-100988 LT-3120 Handset  
 51-101181 LT-3121 Cradle            51-100989 LT-3130 Antenna Unit

**Product Description**  
 The LT-3100 Satellite Communications System is a maritime satellite communication product. The system has voice and data capabilities with global coverage provided by the Iridium® Communications Network. The LT-3100 system consists of a control unit, antenna unit, handset and cradle. The LT-3100 system can be used as the primary satellite communication product on vessels, covering the basic communication needs in terms of connectivity between the ship and shore.

**Declaration**  
 We as manufacturer declare that the above listed product is in conformity with the essential requirements and other relevant requirements of the following Directives:

- Radio Equipment Directive 2014/53/EU**
- RoHS 2 Directive 2011/65/EU**

The following harmonized standards and/or other normative documents were applied in full in accordance to Articles 17 of Directive 2014/53/EU:

| Directive Article | Test of Requirements | Standard & Version   |
|-------------------|----------------------|--|
| Article 3. 1(a)   | Safety               | EN 60950-1:2006+A1:2009+A2:2013, EN 60950-1:2006+A11:2009+A1:2010+A12:2011+A2:2013, EN 60950-22:2006 +A11:2008, EN 60945:2002 Clause 7.2 (Clause 5.3)  |
|                   | Health               | EN 62311:2008  |
| Article 3. 1(b)   | EMC                  | EN 301 489-1:Draft V2.2.0:2017-03, ETSI EN 301 489-17:Draft V3.2.0:2017-03, ETSI EN 301 489-19:Draft V2.1.0:2017-03, EN 55032:2015, EN 61000-4-3:2006 A1:2009 A2:2010, EN 61000-4-4:2012, EN 61000-4-6:2009        |
|                   |                      | EN 60945:2002+C1:2008, Section 8.12, Section 8.2.1, Section 8.2.2, Section 8.3, Section 8.4.1, Section 8.4.2, Section 8.7, Section 12.1, EN 60068-2-27:2009 Section 8 EN 60529:1992+A2:2013 Section 14.2.1, 14.2.2 |
| Article 3. 2      | Radio Spectrum       | EN 60945:2002+C1:2008, (CISPR 16-1-2:2006, CISPR 16-1-4: 2007, EN 61000-4-2:1995, EN 61000-4-3:1996, EN 61000-4-4:1995, EN 61000-4-6:1996, EN 61000-4-11:1994)   |
|                   |                      | EN 300 328:V2.1.1 (2016-11) Clause 4.3.1.10, Clause 4.3.1.11 EN 303 413: V1.1.1 (2017-06) Clause 4.2.2 EN 301 441: V2.1.1 (2016-06) Clause 4.2.1, Clause 4.2.4   |

The conformity assessment procedure referred to in Article 17 and detailed in Annex III of directive 2014/53/EU has been followed with the involvement of the following Notified Body:

**TÜV SÜD BABT, Octagon House, Concorde Way, Segensworth North, Fareham, Hampshire, PO 15 5RL, UK**  
**Identification Number: 0168**  
**Type Examination Certificate No.: BABT-RED001297 I01**

The TCF relevant to the above product will be held at Lars Thrane A/S.

**Place and date**

Holte, 2019-05-03

  
 Peter Thrane, CEO

Lars Thrane A/S

www.thrane.eu

Page 1 of 1

**Lars Thrane A/S**

Skovlytoften 33

2840 Holte

Denmark

[www.thrane.eu](http://www.thrane.eu)