

## Using the VHF 100i and VHF 200i to Program Private Channel Sets

You can program a private channel set using the radio. When you add private channels using the radio to the current International frequency bands. The radio provides only a basic interface for adding private channels. If you require additional programming capabilities, use the Garmin VHF Radio Programmer. The Qatar and United Arab Emirates private channel sets can only be programmed using the Garmin VHF Radio Programmer.

Private channels are inserted at the end of normal radio channels as showing in the following example:

- Private channels added: F1, F2, F3
- Channel ordering on the radio: 87 > 88 > F1 > F2 > F3 > 1 > 2

### To add a private channel set:

1. While pressing and holding the left soft key on the radio, press the **PWR** key to power on the unit. The screen displays "ENTER PASSCODE:".
2. Use the **Channel** knob to enter the passcode: GARMINVHF.
3. Select **OK** to acknowledge the warning message.
4. Select **PRIVATE CH.**
5. Select a private channel set from the list. Select **NONE** to clear a private channel set you have added.

The following table indicates the channel sets that you can add using the radio.

Country	Channel Set	Channel Designator	TX Frequency (MHz)	RX Frequency (MHz)
Belgium	Belgium	96	162.425	162.425
Denmark	Denmark Leis.	L1	155.500	155.500
		L2	155.525	155.525
Denmark	Denmark Fish.	F1	155.625	155.625
		F2	155.775	155.775
		F3	155.825	155.825
Finland	Finland Leis.	L1	155.500	155.500
		L2	155.525	155.525
		L3	155.650	155.650
Finland	Finland Fish.	F1	155.625	155.625
		F2	155.775	155.775
		F3	155.825	155.825
Holland	Holland	37	157.850	157.850
		31	157.550	162.150
Norway	Norway Leis.	L1	155.500	155.500
		L2	155.525	155.525
		L3	155.650	155.650
Norway	Norway Fish.	F1	155.625	155.625
		F2	155.775	155.775
		F3	155.825	155.825
Sweden	Sweden Leis.	L1	155.500	155.500
		L2	155.525	155.525
		L3	155.650	155.650
Sweden	Sweden Fish.	F1	155.625	155.625
		F2	155.775	155.775
		F3	155.825	155.825
United Kingdom	United Kingdom	M1	157.850	157.850
		M2	161.425	161.425

## Using the VHF 100i and VHF 200i to Program ATIS

You can program the inclusion or exclusion of Automatic Transmitter Identification System (ATIS) functionality using the radio.

### To include or exclude ATIS functionality:

1. While pressing and holding the left soft key on the radio, press the **PWR** key to power on the unit. The screen displays "ENTER PASSCODE:".
2. Use the **Channel** knob to enter the passcode: GARMINVHF.
3. Select **OK** to acknowledge the warning message.
4. Select **ATIS FUNCTION**.
5. Select **INCLUDE** or **EXCLUDE**.